

Каталог запасных частей

SY26C

3Y5LU Hydraulic

Excavator

Equipment No. SY0026CA01568

Overview

This book provides illustrations and parts listings required to properly identify and order replaceable parts on your Sany machine.

If this book becomes damaged, lost or illegible, request a replacement copy from your Sany distributor.

In case you sell this machine, be sure to give this parts book to the new owner.

Improvements in the design may lead to changes in detail which may not be indicated in this book. Always consult your Sany distributor for the latest available information on your equipment or if you have questions regarding information in this book.

Storing this parts book

This publication applies only to this specific machine and should not be used with any other machines.

Always keep this book available for reference.

Contact Details

Sany Industrial Park, Economic and Technology Development Zone, Kunshan, Jiangsu, China 215300

Service Hotline: 4008 28 2318


E-mail: crd@sany.com.cn

Website: <http://www.sanyglobal.com>

Sany Group Service Information System

<http://sis.sanygroup.com>

Page header with product name
and machine model



Line-art illustration with
callout numbers

Page footer with page number, parts code, and parts description

Page header with product name
and machine model

Item number that matches
callout numbers on previous
illustration page

Remarks: for complement
information of the part or assembly

Item No.	Part No.	Description	Qty.	Remarks
1	B220401000459	Valve Assembly, Solenoid	1	
2	A820103010415	Change Valve Block, Cooling Oil Motor	1	
3	B220400000083	Relief Valve	1	

Part No.: to be used along
with Description to identify
the part or assembly

Description: to be used
along with Parts No. to
identify the part or assembly

Quantity: it indicates the
number of each part used
in this assembly

Page footer with page number, parts code, and parts description

BLANK PAGE

Table of Contents

Group 1 SY26C3Y5LU Hydraulic Excavator	1-1
SSY100000017 SY26C3Y5LU Hydraulic Excavator	1-2
Group 2 Slewing devic	2-1
SSY004622756 Slewing devic	2-2
SSY004640646 Superstructure Assembly	2-4
13940022 counterweight assembly	2-10
SSY004640651 Hydraulic Main Pipeline	2-12
13919859 oil tube	2-42
60237031 Breather Valve	2-44
60338255 Plunger Pump	2-46
13915468 Bulldozing shovel oil cylinder	2-50
60338118 Multiple valve	2-52
61024024 Inlet Assy	2-54
61024025 Dozer Assy	2-56
61024026 TI Assy	2-58
61024027 Tr Assy	2-60
61024028 Swing Assy	2-62
61024029 Boom Swing Assy	2-64
61024030 Option1 Assy	2-66
61024031 Option2 Assy	2-68
61024032 Boom Assy	2-70
61024033 Arm Assy	2-72
61024034 Bucket Assy	2-74
61024035 End Assy	2-76
60334194 Reducer Assembly	2-78
61024419 Hydraulic Motor	2-80
61024488 Relief Valve	2-82
61024412 Reduction Gears	2-84
SSY004640655 Pilot pipeline	2-86
60342181 Electromagnetic reversal valve	2-140
60247936 Pilot valve	2-142
60129665 Pilot-control Valve	2-144
60281974 Pilot-control Valve	2-148
60281431 Proportional Electromagnetic Valve	2-150
60352306 Pilot valve	2-152
60352305 Pilot valve	2-154
14541994 Pipeline of Boom(with maintaining valve)	2-156
60240905 holding valve	2-164
14542145 Pipeline Of Arm	2-166
13940010 warm air system equip	2-170
60312888 heater assembly SY16	2-172
SSY004677093 Screw plug	2-174
Group 3 Travel device	3-1

14138527 Travel device	3-2
60181276 Tensioner AS	3-8
13863870 Slewing Bearing	3-10
SSY004698999 Dozer Blade	3-12
13915543 Undercarriages hydraulic pipeline	3-14
60022417 Center Swivel Joint	3-22
60334193 Reducer Assembly	3-24
61024425 Reduction Gears	3-26
61024426 Body	3-28
13915446 Bulldozing shovel oil cylinder	3-32

Group 4 Work device 4-1

SSY004622856 Work device	4-2
13915517 Work device Tube	4-14
13915275 Bucket cylinder assembly	4-18
13915265 Bucket Oil Cylinder	4-20
13915254 arm cylinder	4-22
SSY004694494 Connecting Rod Assy	4-24
13919739 Bucket	4-26

Group 5 driver's cab assy. 5-1

13927865 driver's cab assy.	5-2
60341526 Cab	5-8
60349296 front window assembly	5-16
60349303 door assembly	5-18
60166748 rearview	5-20
14422541 Base assembly	5-22
13925246 bracket of display screen	5-24
13603246 pendulum pedal assy	5-26
13967294 running control mechanism	5-28
13603240 pedal assy	5-30
13603236 pedal assy	5-32
13927274 maintenance cover	5-34
60328847 Driver cab seat	5-36
60223376 Left armrest box assembly	5-38
60346062 Right armrest box assembly	5-40

Group 6 general assembly of covering parts 6-1

14139093 general assembly of covering parts	6-2
13938368 front engine hood assy	6-4
13938344 assembly of rear hood	6-6

Group 7 Electrical assembly drawing 7-1

14136941 Electrical assembly drawing	7-2
12824424 Integrated box	7-6

Group 8 Coating 8-1

14000776 Coating	8-2
------------------------	-----


Group 9 Attached accessories 9-1

14532950 Attached accessories	9-2
14042474 Accompanying tools.....	9-4
A290000000155 Toolbox, portable	9-6

BLANK PAGE

Group 1

SY26C3Y5LU Hydraulic Excavator












No.	Part No.	Description	Qty	Page number
1	SSY004622756	Slewing devic	1	2-2
2	14138527	Travel device	1	3-2
3	SSY004622856	Work device	1	4-2
4	13927865	driver's cab assy.	1	5-2
5	14139093	general assembly of covering parts	1	6-2
6	14138545	power system	1	
7	14136941	Electrical assembly drawing	1	7-2
8	14000776	Coating	1	8-2
9	14532950	Attached accessories	1	9-2


BLANK PAGE

Group 2


Slewing devic




No.	Part No.	Description	Qty	Page number
1	SSY004640646	Superstructure Assembly	1	2-4
2	SSY004640651	Hydraulic Main Pipeline	1	2-12
3	SSY004640655	Pilot pipeline	1	2-86
4	14541994	Pipeline of Boom(with maintaining valve)	1	2-156
5	14542145	Pipeline Of Arm	1	2-166
8	13940010	warm air system equip	1	2-170
9	SSY004677093	Screw plug	1	2-174




No.	Part No.	Description	Qty	Page number
1	13916934	Shaft Sleeve	2	
2	13937753	revolving frame	1	
3	13940022	counterweight assembly	1	2-10
4	21053360	Hose ring hoop	2	
5	A210307000001	Nut	2	
6	14172251	bracket	1	
7	A210111000323	Bolt	1	
8	A229900000882	Valve	1	
9	13055186	water_out_joint	2	
10	13494001	drainage tube	1	



No.	Part No.	Description	Qty	Page number
5	A210307000001	Nut	2	
21	A210110000323	Bolt	1	
22	13085812	Spacer	8	
23	13036961	Lock pin	1	
32	A210804000002	Adaptor Grease	3	
33	A229900010160	Pipe connector	3	
34	23000531	Stud Ends	1	
35	B230103002042	hose	1	
36	12877195	G1/4(ED)-M14Connector	1	
37	A831213044000	Rubber Hose 1SN6-DKOL-DKOL90-440	1	
38	B230103007052	Hose	1	
39	A820205000858	Fitting	1	




No.	Part No.	Description	Qty	Page number
11	14203224	sponge	1	
12	14203225	sponge	1	
13	14203221	sponge	1	
14	14203220	sponge	1	
15	14203222	sponge	1	
16	14203227	sponge	1	
17	11225694	Protective sleeve	1	
18	A210111000343	Bolt	4	
19	12996227	cover plate	1	
20	13068305	Spacer	1	
24	14203226	sponge	1	
25	14203228	sponge	1	
26	14203223	sponge	1	
27	14203218	sponge	1	
28	14203219	sponge	1	
29	14203217	sponge	1	
30	13932946	Sealing Plate	1	
31	A210404000005	Washer	3	
40	24000633	Washer	2	
41	60086354	Clamp	1	





No.	Part No.	Description	Qty	Page number
1	13913236	counterweight	1	
2	A210111000321	Bolt	3	
3	A210491000122	Washer	3	

Main Valve




No.	Part No.	Description	Qty	Page number
25	60338118	Multiple valve	1	2-52
26	A210111000323	Bolt	3	
27	24000633	Washer	3	
45	11147213	G1/2(ED)-M26-L65 connector	2	
53	B210780000016	Fitting Tee L-Shape	1	
54	B210780000180	Connector, Pipe	6	
55	13053059	connector	4	
57	B210780000177	Connector, pipe	2	
58	12978957	Connector	2	
59	B210780000179	Fitting, Adapter	3	
61	21053567	Pipe connector	1	
65	B210780001310	Fitting, Elbow	1	
66	B210780000024	Fitting Elbow	10	

Pump




No.	Part No.	Description	Qty	Page number
4	24000637	Washer	6	
6	A210204000337	Screw	14	
7	24000639	Washer	14	
13	60338255	Plunger Pump	1	2-46
14	B210780000244	Flange, Split	2	
15	21011030	Fitting, Adapter, Flange	1	
16	B210780000029	Fitting, Elbow	1	
24	A210608000077	O-ring	2	
28	14210440	lengthening adaptor	1	
31	13919911	Oil suction steel tube	1	
43	A210204000354	Screw	4	

Reducer Assembly




No.	Part No.	Description	Qty	Page number
37	60334194	Reducer Assembly	1	2-78
38	A210204000203	Screw	6	
39	24000642	Washer	6	
56	B230101000049	O-ring	3	
60	A820205002389	G3/8-M18 connector	3	
66	B210780000024	Fitting Elbow	10	

Ball Valve





No.	Part No.	Description	Qty	Page number
10	24000632	Washer	6	
11	60246980	ball valve	1	
12	A210204000137	Screw	2	
59	B210780000179	Fitting, Adapter	3	
66	B210780000024	Fitting Elbow	10	

Radiator




No.	Part No.	Description	Qty	Page number
40	B210780001007	Fitting, Tee	1	
41	A229900010390	Fitting, Adapter	1	
45	11147213	G1/2(ED)-M26-L65 connector	2	

Center Swivel Joint




No.	Part No.	Description	Qty	Page number
32	13603282	Connector	1	
42	B210780000636	Fitting, Elbow	1	
62	B210780000609	Plug	2	
63	B210780000036	Connector, Pipe	1	
64	B210780000232	Connector, Pipe	4	
66	B210780000024	Fitting Elbow	10	




No.	Part No.	Description	Qty	Page number
5	13919859	oil tube	1	2-42
6	A210204000337	Screw	14	
7	24000639	Washer	14	
8	60237031	Breather Valve	1	2-44
9	A210204000130	Screw	4	
10	24000632	Washer	6	
20	10514225	Screw plug	1	
21	10165802	Connector	1	
23	13919934	Oil suction steel tube	1	
24	A210608000077	O-ring	2	

Suction Hose




No.	Part No.	Description	Qty	Page number
29	14157352	Suction Hose	1	
30	A210855000024	Hoop	4	

(&)
Tube(Hydraulic Oil Tan & Radiator)




No.	Part No.	Description	Qty	Page number
19	B230103004072	Rubber Hose	1	

(&)
Tube(Bucket & Boom Swing)




No.	Part No.	Description	Qty	Page number
1	13919943	Clamp	1	
2	13919944	plate	1	
3	A210204000335	Screw	2	
4	24000637	Washer	6	
22	13915468	Bulldozing shovel oil cylinder	1	2-50
34	B230103000464	Rubber hose	1	
35	151003210024A	Hose	1	
50	13182689	Rubber hose	1	
52	B230103004297	Rubber hose	1	

胶管(回转)
Tube(Swing)




No.	Part No.	Description	Qty	Page number
36	60243801	rubber hose	1	
44	B230103006585	Rubber Hose	1	
49	151004210029A	Hose	3	

()
Tube(Dozer)




No.	Part No.	Description	Qty	Page number
46	151003210023A	Hose	2	

(&)
Tube(Hammer & Radiator)




No.	Part No.	Description	Qty	Page number
17	151004210031A	Hose	3	
18	B230103004806	Rubber Hose	1	
51	B230103003389	Hose	1	

()
Tube(LH Travel)




No.	Part No.	Description	Qty	Page number
33	151006210006A	Hose	1	
49	151004210029A	Hose	3	


()
Tube(RH Travel)




No.	Part No.	Description	Qty	Page number
47	151004210027A	Rubber hose	1	
48	60101296	Rubber hose	1	




No.	Part No.	Description	Qty	Page number
1	A210111000343	Bolt	8	
2	24000511	Washer	8	
3	24000633	Washer	8	
4	13920376	plate	1	
5	A210608000018	O-ring	1	
6	60167908	Filtercore	1	
7	13920373	hydraulic oil tan	1	
8	13061324	plate	1	
9	A880802040016	O-ring	1	
10	60114999	Filter core	1	
11	A250100000174	Gauge, sight glass	1	
12	B230101000356	O-ring	1	
13	10514225	Screw plug	1	





No.	Part No.	Description	Qty	Page number
1	60174894	Filter, hydraulic tank breather	1	




No.	Part No.	Description	Qty	Page number
1	61008600	Lock Nut	1	
2	61008601	Lock Nut	1	
3	61008437	Flow Compensator	1	
4	61008438	Torque Limiter	1	
5	61008439	Flow Compensator	1	
10	61008444	Screw	4	
13	61008447	Nut	2	
15	61008449	Screw	1	
19	61008454	O-Ring	2	
21	61008456	O-Ring	1	
23	61008457	Ring	1	
25	61008459	Ring	1	
34	61008468	Swash Plate	1	
42	61008476	Piston	1	
49	61008483	Plug	2	
50	61008484	Plug	3	




No.	Part No.	Description	Qty	Page number
6	61008440	Cover	1	
7	61008441	Roller Bearing	1	
8	61008442	Roller Bearing	1	
9	61008443	Screw	1	
11	61008445	Screw	1	
12	61008446	Screw	4	
14	61008448	Screw	2	
17	61008452	Shoulder Washer	1	
18	61008453	O-Ring	1	
20	61008455	O-Ring	1	
22	60249509	SHAFT SEAL BABSL 28X40X7	1	
24	61008458	Ring	1	
26	61008460	Support Drive Torque Limiter	1	
27	61008461	Eccentric Drive Torque Limiter	1	
28	61008462	Splined Ring	1	
29	61008463	Semi-Ring Swash Plate Support	2	
30	61008464	Cylinders Block	1	
31	61008465	Counterbalancing Spring	1	
32	61008466	Pistons Spring	1	
33	61008467	Connector	1	
35	61008469	Pistons Guide Plate	1	
36	61008470	Valve Plate	1	
37	61008471	Piston	9	
38	61008472	Connection Shaft	1	
39	61008473	Shaft	1	
40	61008474	Segment	1	
41	61008475	Pump Body	1	
43	61008477	Dowel Pin Elastic	1	
44	61008478	Dowel Pin Casehardened	3	
45	61008479	Dowel Pin Elastic	2	
46	61008480	Dowel Pin Casehardened	1	
47	61008481	Dowel	1	
48	61008482	Plug	1	
51	61008485	Plug	5	
52	61008485	Plug	1	
53	61008486	Plunger Pump Repair Kit	1	




No.	Part No.	Description	Qty	Page number
1	13928220	sealer package	1	




No.	Part No.	Description	Qty	Page number
1	61024024	Inlet Assy	1	2-54
2	61024025	Dozer Assy	1	2-56
3	61024026	TI Assy	1	2-58
4	61024027	Tr Assy	1	2-60
5	61024028	Swing Assy	1	2-62
6	61024029	Boom Swing Assy	1	2-64
7	61024030	Option1 Assy	1	2-66
8	61024031	Option2 Assy	1	2-68
9	61024032	Boom Assy	1	2-70
10	61024033	Arm Assy	1	2-72
11	61024034	Bucket Assy	1	2-74
12	61024035	End Assy	1	2-76
13	61024055	Stud Bolt	4	
14	61020153	Nut	4	
15	61024073	Main Valve Repair Kit	1	




No.	Part No.	Description	Qty	Page number
1	61024047	Inlet Valve Block	1	
2	61024053	LS Flow Valve	1	
3	61024071	Safety Valve	1	
8	61020174	Plug	2	
9	61024044	Unload Spool	1	
10	61024050	Spring Seat	1	
11	61024068	Spring	1	
12	61020169	O-ring	1	
13	61024064	Plug	1	
14	61024057	O Ring	3	
15	61020176	O-ring	1	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024070	Relief Valve	2	
5	61024043	Dozer Spool	1	
6	61024059	O Ring	2	
7	61024051	Spring Seat	2	
8	61024069	Spring	2	
9	61024052	Spring Seat	2	
10	61024036	End Cover	2	
13	61024056	Screw	8	
14	61024057	O Ring	3	
15	61020176	O-ring	1	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61024054	Check Valve	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
4	61024046	Travel Spool	1	
5	61024059	O Ring	2	
6	61024051	Spring Seat	2	
7	61024069	Spring	2	
8	61024052	Spring Seat	2	
9	61024036	End Cover	2	
12	61024056	Screw	8	
13	61024057	O Ring	3	
14	61020176	O-ring	2	
15	61024063	Plug	1	
16	61024058	O Ring	1	
17	61024045	Compensator spool	1	
18	61020201	O-ring	2	
19	61024062	Plug	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024065	Restrictor	1	
5	61024046	Travel Spool	1	
6	61024059	O Ring	2	
7	61024051	Spring Seat	2	
8	61024069	Spring	2	
9	61024052	Spring Seat	2	
10	61024036	End Cover	2	
13	61024056	Screw	8	
14	61024057	O Ring	3	
15	61020176	O-ring	1	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61020201	O-ring	2	
20	61024062	Plug	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
4	61024042	Swing Spool	1	
5	61024059	O Ring	2	
6	61024051	Spring Seat	2	
7	61024069	Spring	2	
8	61024052	Spring Seat	2	
9	61024036	End Cover	2	
12	61024056	Screw	8	
13	61024057	O Ring	3	
14	61020176	O-ring	1	
15	61024063	Plug	1	
16	61024058	O Ring	1	
17	61024045	Compensator spool	1	
18	61024054	Check Valve	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024070	Relief Valve	2	
3	61024041	Boom Swing Spool	1	
4	61024059	O Ring	2	
5	61024051	Spring Seat	2	
6	61024069	Spring	2	
7	61024052	Spring Seat	2	
8	61024036	End Cover	2	
9	61024056	Screw	8	
10	61024057	O Ring	3	
11	61020176	O-ring	1	
12	61024063	Plug	1	
13	61024058	O Ring	1	
14	61024045	Compensator spool	1	
15	61024054	Check Valve	2	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61024054	Check Valve	1	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024072	Relief Valve	2	
5	61024040	Option Spool	1	
6	61024059	O Ring	2	
7	61024051	Spring Seat	2	
8	61024069	Spring	2	
9	61024052	Spring Seat	2	
10	61024036	End Cover	2	
13	61024056	Screw	8	
14	61024057	O Ring	3	
15	61020176	O-ring	1	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61024054	Check Valve	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024070	Relief Valve	2	
5	61024040	Option Spool	1	
6	61024059	O Ring	2	
7	61024051	Spring Seat	2	
8	61024069	Spring	2	
9	61024052	Spring Seat	2	
10	61024036	End Cover	2	
13	61024056	Screw	8	
14	61024057	O Ring	3	
15	61020176	O-ring	1	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61024054	Check Valve	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024070	Relief Valve	2	
5	61024039	Boom Spool	1	
6	61024059	O Ring	2	
7	61024051	Spring Seat	2	
8	61024069	Spring	2	
9	61024052	Spring Seat	2	
10	61024036	End Cover	2	
13	61024056	Screw	8	
14	61024057	O Ring	3	
15	61020176	O-ring	1	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61024054	Check Valve	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024070	Relief Valve	2	
5	61024038	Arm Spool	1	
6	61024059	O Ring	2	
7	61024051	Spring Seat	2	
8	61024069	Spring	2	
9	61024052	Spring Seat	2	
10	61024036	End Cover	2	
13	61024056	Screw	8	
14	61024057	O Ring	3	
15	61020176	O-ring	1	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61024054	Check Valve	2	




No.	Part No.	Description	Qty	Page number
1	61024048	Arm Valve Block	1	
2	61024070	Relief Valve	2	
5	61024037	Bucket Spool	1	
6	61024059	O Ring	2	
7	61024051	Spring Seat	2	
8	61024069	Spring	2	
9	61024052	Spring Seat	2	
10	61024036	End Cover	2	
13	61024056	Screw	8	
14	61024057	O Ring	3	
15	61020176	O-ring	1	
16	61024063	Plug	1	
17	61024058	O Ring	1	
18	61024045	Compensator spool	1	
19	61024054	Check Valve	2	




No.	Part No.	Description	Qty	Page number
1	61024049	End Valve Block	1	
2	61024067	Rubber Mat	2	
3	61024061	Plug	2	
6	61024066	Washer	1	
7	61024060	Plug	1	




No.	Part No.	Description	Qty	Page number
1	61024419	Hydraulic Motor	1	2-80
2	61024412	Reduction Gears	1	2-84






No.	Part No.	Description	Qty	Page number
201	61024510	Body	1	
202	61024526	Plate	1	
203	61024527	Shaft	1	
204	61024515	Cylinder Barrel	1	
205	61024516	Valve Plate	1	
206	61024517	Piston	9	
207	61024518	Shoe	9	
208	61024519	Shoe Holder	1	
209	61024520	Barrel Holder	1	
210	61024524	Swash Plate	1	
212	61024521	Seat	2	
213	61024522	Pin	3	
214	60258113	FILTER	1	
215	61024523	Spring	1	
216	61024424	Bearing	1	
217	61024421	Bearing	1	
221	60258116	SNAP RING	1	
223	60164310	SCREW	12	
224	61024511	Spring Pin	1	
225	60164322	PIN	3	
226	61024525	Pin	1	
231	61024528	Brake Piston	1	
233	61024529	Disk Plate	1	
235	60257745	O RING	1	
236	60164378	O RING	1	
243	61024488	Relief Valve	2	2-82
246	61024512	Check Valve	2	
247	61024513	Plug	2	
248	61024514	Spring	2	
249	60164379	O RING	2	
251	61024423	Swash Plate Group	1	
252	61024422	Brake Piston Group	1	
253	61024420	Body Group	1	
254	60164336	Kit, seal	1	




No.	Part No.	Description	Qty	Page number
301	61024530	Seat	1	
302	61024531	Body	1	
303	61024532	Poppet	1	
304	61024533	Piston	1	
305	61024534	Cap	1	
306	61024535	Spring	1	
307	61024536	Washer	1	
308	60164380	O RING	1	
309	60164384	O RING	1	
310	60164385	O RING	1	
311	60164381	O RING	1	
312	61024537	Back Up Ring	2	
320	60258139	Kit, seal	1	




No.	Part No.	Description	Qty	Page number
101	61024489	Body	1	
102	61024498	Carrier 1	1	
103	61024504	Carrier 2	1	
104	61024490	Shaft	1	
105	61024491	Internal Gear	1	
106	61024499	Gear B1	4	
107	61024505	Gear B2	3	
108	61024416	Sun Gear S1	1	
109	60258082	S2 GEAR	1	
111	61024500	Needle	92	
112	61024506	Needle	72	
113	61024492	Ring Seal	1	
114	61024417	O Ring	1	
115	61024501	Thrust Plate1	1	
116	61024507	Thrust Plate 2	1	
117	61024502	Thrust Washer1	4	
118	61024508	Thrust Washer 2	3	
119	61024493	Pre-Load Callar	2	
120	60258092	SNAP RING	4	
121	61024494	Bearing	1	
122	61024495	Bearing	1	
123	61024496	Oil Seal	1	
124	60164310	SCREW	6	
126	61024497	Pin	2	
128	61024418	Ring Retaining	1	
129	61024503	Ring 1	4	
130	61024509	Ring 2	3	
131	61024413	Pinion Gear Group	1	
132	61024414	Gear Group 1	1	
133	61024415	Gear Group 2	1	




No.	Part No.	Description	Qty	Page number
1	60342181	Electromagnetic reversal valve	1	2-140
2	A210204000147	Screw	2	
3	24000633	Washer	2	
4	B210780000176	Fitting, Adapter	9	
5	B210780000170	Fitting, Tee, L-shape	5	
6	60136966	Pipe connector	7	
7	B210780000418	Fitting Elbow	11	
10	23904681	Pipe connector	38	




No.	Part No.	Description	Qty	Page number
6	60136966	Pipe connector	7	
8	B210780000024	Fitting Elbow	5	
9	B2107800000827	Connector Pipe	2	
10	23904681	Pipe connector	38	
11	60140964	Pipe connector	6	
12	B2299000000063	Filter, pilot AS	1	
14	A210111000343	Bolt	4	



No.	Part No.	Description	Qty	Page number
4	B210780000176	Fitting, Adapter	9	
5	B210780000170	Fitting, Tee, L-shape	5	
6	60136966	Pipe connector	7	
7	B210780000418	Fitting Elbow	11	
10	23904681	Pipe connector	38	
15	B210780000172	Fitting	2	
16	B210780001045	Fitting	5	
17	A820205001061	Sensor, pressure	1	
18	60114799	Pressure Sensor	1	
19	B210780000823	Stud Straight Connector	26	




No.	Part No.	Description	Qty	Page number
5	B210780000170	Fitting, Tee, L-shape	5	
6	60136966	Pipe connector	7	
7	B210780000418	Fitting Elbow	11	
10	23904681	Pipe connector	38	
16	B210780001045	Fitting	5	
20	21011540	Pipe connector	4	
21	B230101000047	O-ring	8	
22	B210780000014	Pipe connector	5	
23	A210204000196	Screw	4	
25	60129665	Pilot-control Valve	1	2-144
26	13623064	G1/4-M14 Connector	2	
27	A820205000944	Adapter, relay	2	
28	B240700000221	Pressure relay	2	
29	B220400000169	Valve, shuttle, tee	2	
30	60175301	Pipe connector	4	



No.	Part No.	Description	Qty	Page number
10	23904681	Pipe connector	38	
19	B210780000823	Stud Straight Connector	26	
24	60247936	Pilot valve	1	2-142
30	60175301	Pipe connector	4	
31	60249819	Screw	10	
32	60027775	Washer	10	

()


Pilot-control Valve(Boom Swing)




No.	Part No.	Description	Qty	Page number
10	23904681	Pipe connector	38	
11	60140964	Pipe connector	6	
19	B210780000823	Stud Straight Connector	26	
31	60249819	Screw	10	
32	60027775	Washer	10	
33	60281974	Pilot-control Valve	1	2-148




No.	Part No.	Description	Qty	Page number
10	23904681	Pipe connector	38	
11	60140964	Pipe connector	6	
19	B210780000823	Stud Straight Connector	26	
22	B210780000014	Pipe connector	5	
34	60281431	Proportional Electromagnetic Valve	1	2-150
35	60225886	Bolt	2	




No.	Part No.	Description	Qty	Page number
7	B210780000418	Fitting Elbow	11	
8	B210780000024	Fitting Elbow	5	
13	A229900010160	Pipe connector	1	
21	B230101000047	O-ring	8	
40	A820205000940	Fitting	2	
74	B210780000143	Connector, pipe	1	




No.	Part No.	Description	Qty	Page number
21	B230101000047	O-ring	8	
37	A820205002389	G3/8-M18 connector	1	
38	B230101000049	O-ring	1	
39	B210780000019	Fitting, tee, L-shape	1	
40	A820205000940	Fitting	2	




No.	Part No.	Description	Qty	Page number
41	B210780000232	Connector, Pipe	1	
42	12978991	Connector	1	




No.	Part No.	Description	Qty	Page number
4	B210780000176	Fitting, Adapter	9	
7	B210780000418	Fitting Elbow	11	
8	B210780000024	Fitting Elbow	5	
36	B210780000180	Connector, Pipe	2	




No.	Part No.	Description	Qty	Page number
31	60249819	Screw	10	
32	60027775	Washer	10	
43	60352306	Pilot valve	1	2-152
45	60060564	Washer	6	
46	60352305	Pilot valve	1	2-154




No.	Part No.	Description	Qty	Page number
69	B230103004426	Rubber hose	1	
72	21020859	Rubber Hose	1	



No.	Part No.	Description	Qty	Page number
73	B230103000932	Hose AS	1	
75	B230103002263	Hose Assembly	1	




No.	Part No.	Description	Qty	Page number
63	60246041	rubber hose	1	
71	21054224	Rubber Hose	1	




No.	Part No.	Description	Qty	Page number
66	60255796	RubberHose	3	
68	B230103007708	Rubber Hose	1	
70	A831213044000	Rubber Hose 1SN6-DKOL-DKOL90-440	1	


VIEW_P




No.	Part No.	Description	Qty	Page number
62	B230103000995	Hose	1	
66	60255796	RubberHose	3	
67	60018916	Rubber Hose	1	



No.	Part No.	Description	Qty	Page number
54	60120223	Rubber Hose	1	
66	60255796	RubberHose	3	




No.	Part No.	Description	Qty	Page number
50	60120213	Rubber Hose	1	
51	60120209	Rubber Hose	2	




No.	Part No.	Description	Qty	Page number
51	60120209	Rubber Hose	2	
64	60262327	rubber hose	2	

BOOM SWING



No.	Part No.	Description	Qty	Page number
55	60120222	Rubber Hose	1	
56	60238497	Rubber Hose	3	
59	60120224	Rubber Hose	1	




No.	Part No.	Description	Qty	Page number
49	60120210	Rubber Hose	1	
61	60120215	Rubber Hose	1	
65	60120208	Rubber Hose	2	

Diagram illustrating the connection of a hose (53) to a manifold (58) and a pump (57). The manifold (58) is shown with multiple ports, including a2 and b2. The pump (57) is connected to the manifold via the hose (53). A pressure arrow 'P' indicates the flow direction from the pump.

No.	Part No.	Description	Qty	Page number
53	60227817	Rubber Hose	2	
57	60270116	rubber hose	1	
58	60323298	Rubber hose	1	




No.	Part No.	Description	Qty	Page number
53	60227817	Rubber Hose	2	
54	60120223	Rubber Hose	1	
56	60238497	Rubber Hose	3	




No.	Part No.	Description	Qty	Page number
44	60120211	Rubber Hose	1	
64	60262327	rubber hose	2	


BOOM SWING




No.	Part No.	Description	Qty	Page number
52	60262330	rubber hose	1	
60	60240242	rubber hose	1	



No.	Part No.	Description	Qty	Page number
47	60120214	Rubber Hose	1	
48	60120217	Rubber Hose	1	




No.	Part No.	Description	Qty	Page number
1	61016947	Accumulator	1	
2	61016949	O-Ring	1	
3	61016948	Accumulator connector	1	
4	61016952	O-Ring	2	
5	61016951	Spring	1	
6	61016950	Ball	1	
7	61016944	Mhste Housing	1	
8	61016945	Electromagnetic valve	2	
9	61016946	Coil	2	
10	61016956	Cone	1	
11	61016961	Spring	1	
12	61016962	Spacer	1	
13	61016960	Plug	1	
14	61016955	Reducer hosing	1	
15	61016957	O-Ring	1	
16	61016958	Spacer	1	
17	61016959	Spring	1	
18	61016963	Plug	5	
19	61016954	Reducer spool	1	
20	61016953	Plug	1	
21	61016964	Oil source valve repair kit	1	




No.	Part No.	Description	Qty	Page number
1	60290358	Body	1	
2	A210608000007	O-ring	2	
3	60290359	Valve pocket	2	
4	60290360	Spool	2	
5	60290361	Spring washer	2	
6	60290362	Spring	2	
7	60290363	Spring	2	
8	60290364	Seat	2	
9	60290365	Washer	4	
10	B230101000049	O-ring	2	
11	60290366	Steel-wire retainer ring	2	
12	60290367	Piston Rod	2	
13	60290368	Copper sleeve	2	
14	60290369	U ring	2	
15	21019042	O-ring	2	
16	A210414000003	Retainer Ring	2	
17	60290370	Pin	1	
18	60290371	Seat	1	
19	60290372	Swing holder	1	
20	A210204000134	Screw	2	
21	60290373	Screw	2	
22	A210307000015	Nut	2	
23	A210307000012	Nut	1	
24	60290374	Joystick assembly	1	
25	60290375	Dust Cover	1	
26	60290376	Screw	1	
27	60290377	Cap	1	
28	150588000006	Repair Kit	1	

No.	Part No.	Description	Qty	Page number
1	11578416	washer	4	
2	60171688	Protective sleeve	2	
3	60171541	Plug	4	
4	60171597	Spool Guide	2	
5	60171675	Pin	2	
6	60171644	Fixed plate	2	
7	60171656	Screw	4	
8	60171567	Steel ball	4	
9	60171676	Pin	4	
10	60171550	Retaining ring	4	
11	60171672	Push rod assembly	4	




No.	Part No.	Description	Qty	Page number
12	60171686	plunger assembly	1	
13	60171613	Spring	2	
14	60171614	Spring	2	
15	60171582	Spool	2	
16	60141820	Cross recessed pan head tapping screws	2	
17	60171658	Nameplate	1	
18	60171572	Body of valve	1	
19	A210608000073	O-ring	1	
20	60082841	Screw Plug	1	
21	60147943	Plug	1	
22	A210609000095	O-ring	1	


No.	Part No.	Description	Qty	Page number
1	A210608000007	O-ring	2	
2	60290359	Valve pocket	2	
3	60290360	Spool	2	
4	60290361	Spring washer	2	
5	60290362	Spring	2	
6	60290363	Spring	2	
7	60290364	Seat	2	
8	60290365	Washer	4	
9	B230101000049	O-ring	2	
10	60290366	Steel-wire retainer ring	2	
11	60290367	Piston Rod	2	
12	60290368	Copper sleeve	2	
13	60290369	U ring	2	
14	21019042	O-ring	2	
15	A210414000003	Retainer Ring	2	
16	60290370	Pin	1	
17	60290371	Seat	1	
18	60290372	Swing holder	1	
19	A210204000134	Screw	2	
20	A210307000015	Nut	2	
21	60290373	Screw	2	
22	A210414000003	Retainer Ring	2	




No.	Part No.	Description	Qty	Page number
1	61025254	Bolt, socket head	4	
2	61025255	Solenoid valve	2	
3	61025256	Valve block	1	





No.	Part No.	Description	Qty	Page number
1	60259205	Nut	1	
2	60221098	Soffietto Circolare	1	
3	60171553	Retaining ring	1	
4	61026666	Universal joint	1	
5	60221097	FLANGE	1	
6	60171579	Body of valve	1	
7	61026667	Joint	6	
8	60171687	Plunger AS	4	
9	60171551	Retaining ring	4	
10	60171619	Spring	4	
11	60221100	SPRING	4	
12	60221102	BUSHING	4	
13	60171583	Spool	4	
14	60238623	Rubber Sleeve	1	
15	61026665	Nut	2	
16	61026664	Connecting rod	1	
17	61026661	Connector	1	
18	61026663	Handle	1	
19	61026669	Repair kit,handle	1	




No.	Part No.	Description	Qty	Page number
1	60259205	Nut	1	
2	60221098	Soffietto Circolare	1	
3	60171553	Retaining ring	1	
4	61026666	Universal joint	1	
5	60221097	FLANGE	1	
6	60171579	Body of valve	1	
7	61026667	Joint	6	
8	60171687	Plunger AS	4	
9	60171551	Retaining ring	4	
10	60171619	Spring	4	
11	60221100	SPRING	4	
12	60221102	BUSHING	4	
13	60171583	Spool	4	
14	60238623	Rubber Sleeve	1	
15	61026665	Nut	2	
16	61026664	Connecting rod	1	
17	61026661	Connector	1	
18	61026662	Handle	1	
19	61026668	Repair kit,handle	1	




No.	Part No.	Description	Qty	Page number
3	B210780001391	Swivel Reducing Straight Adapter	1	
4	23904681	Pipe connector	2	
5	B230101000047	O-ring	1	
6	A820205000940	Fitting	1	
7	23000063	Screw	1	
8	60240905	holding valve	1	2-164
9	B230101000090	O-Ring	2	
10	10541251	Connector	2	
11	B210780000024	Fitting Elbow	1	




No.	Part No.	Description	Qty	Page number
4	23904681	Pipe connector	2	
12	B210780000823	Stud Straight Connector	2	
13	B210780000180	Connector, Pipe	1	
14	13053059	connector	1	
15	B210780000014	Pipe connector	1	
16	60175301	Pipe connector	2	




No.	Part No.	Description	Qty	Page number
2	B210780000170	Fitting, Tee, L-shape	1	
17	60120212	Rubber Hose	1	
18	60120217	Rubber Hose	1	
19	60120222	Rubber Hose	1	
22	B230103003046	Rubber Hose	1	




No.	Part No.	Description	Qty	Page number
1	B210780000115	Fitting, Bulkhead Connector	2	
20	B230103005165	Rubber hose	1	
21	151004210031A	Hose	1	
22	B230103003046	Rubber Hose	1	
23	B230103004297	Rubber hose	1	
24	B230103003866	Rubber hose	2	




No.	Part No.	Description	Qty	Page number
1	60290332	Connection	1	
2	60290333	Plug	1	
3	21029124	O-ring	1	
4	60290334	Control piston	1	
5	60290335	Spring	1	
6	60290336	Piston cover	1	
7	60290337	O ring	2	
8	60290338	Piston Rod	1	
9	60290339	Control Rod	1	
10	60290340	Nut	1	
11	60290341	Bolt	1	
12	60290342	Valve pocket	1	
13	60290343	Piston	1	
14	A210608000007	O-ring	1	
15	60290344	Spring	1	
16	60290345	Poppet	1	
17	60290346	Plug	2	
18	60290347	Spool	1	
19	60290348	Washer	1	
20	60290349	Spring	1	
21	21000123	O-ring	1	
22	60290350	Plug	1	
23	60290351	Plug	1	
24	60290352	Seal Washer	1	
25	60290353	Spring	1	
26	60290354	Retainer ring	2	
27	B230101000679	O-ring	1	
28	60290355	Spool	1	
29	60290356	Plug	5	
30	60290357	Body	1	




No.	Part No.	Description	Qty	Page number
1	B210780000823	Stud Straight Connector	2	
2	23904681	Pipe connector	2	
3	B210780000180	Connector, Pipe	1	
4	13053059	connector	1	
7	13182689	Rubber hose	2	




No.	Part No.	Description	Qty	Page number
5	60120212	Rubber Hose	1	
6	60120213	Rubber Hose	1	



No.	Part No.	Description	Qty	Page number
1	60312888	heater assembly SY16	1	2-172
2	13202041	water pipe	2	
3	13699569	transitional joint	1	
4	13699488	three-way joint	1	
5	60166393	Split flow gear pump	4	
6	13036166	Protective sleeve	1	
7	A210111000240	Bolt	4	
8	24000633	Washer	4	



No.	Part No.	Description	Qty	Page number
1	60330156	Blower	1	
2	60330155	Windshield switch	1	
3	60330758	Valve-heater	1	
4	60330154	Joint valve	1	




No.	Part No.	Description	Qty	Page number
1	B210780000164	Screw Plug	2	
2	B210399000001	Screw plug	2	


BLANK PAGE

Group 3


Travel device




No.	Part No.	Description	Qty	Page number
1	60343115	Rubber crawler	2	
2	13891370	guide wheel assy.	2	
3	60181276	Tensioner AS	2	3-8
4	A210491000121	Washer	44	
5	A210204000337	Screw	56	
6	12935633	track roller	8	
7	A210444000001	Washer	16	
8	A210111000442	Bolt	12	
9	A210111000209	Bolt	4	
10	13891396	Driving wheel	2	
11	13922934	Combination Running frame	1	
12	21005237	Bolt	40	
13	13863870	Slewing Bearing	1	3-10
29	A210111000343	Bolt	7	
30	24000633	Washer	7	
35	14518215	cover plate	2	




No.	Part No.	Description	Qty	Page number
14	SSY004698999	Dozer Blade	1	3-12
15	10597771	Cover board	1	
16	A210111000012	Bolt	14	
17	24000637	Washer	14	
18	A210804000002	Adaptor Grease	1	
19	13085812	Spacer	8	
20	60176725	Dust Ring	4	
21	13036961	Lock pin	2	
22	A210110000014	Bolt	2	
23	A210307000031	Nut	8	
24	13063804	Spacer	8	
25	13036922	Lock pin	2	
26	A210110000323	Bolt	2	




No.	Part No.	Description	Qty	Page number
16	A210111000012	Bolt	14	
17	24000637	Washer	14	
27	13919848	Motor cover	2	
28	11133805	Protective Sleeve	2	
29	A210111000343	Bolt	7	
30	24000633	Washer	7	
31	13040450	bottom cover plate	1	
32	11133774	Protective Sleeve	2	
33	13915543	Undercarriages hydraulic pipeline	1	3-14
34	10514225	Screw plug	1	




No.	Part No.	Description	Qty	Page number
1	60248022	Refiller Valve	1	
2	60280434	mandrel	1	
3	60248024	Dust Ring	1	
4	60248025	Bearing Ring	1	
5	60248026	Seal Ring	1	
6	60280435	body cylinder	1	
7	60280436	spring	1	
8	60280437	spring plate	1	
9	60280438	installation plate	1	
10	A210111000206	Bolt	2	
11	60248023	Tensioning Equipment Repairing Bag	1	




No.	Part No.	Description	Qty	Page number
1	60205959	Angle sealing strip	2	
2	13863860	Outer Ring	1	
3	60307398	Steel Ball	66	
4	60328517	Spherical separators	66	
5	13863791	Inner Ring	1	
6	13863863	pumping	1	
7	60012591	Pin	1	
8	60078066	Pin	1	




No.	Part No.	Description	Qty	Page number
1	13919736	Bulldozing shovel	1	
2	13036982	Shaft Sleeve	2	




No.	Part No.	Description	Qty	Page number
1	60022417	Center Swivel Joint	1	3-22
2	B210780000232	Connector, Pipe	4	
3	B210780000609	Plug	2	
4	B210780000174	Connectorpipe	2	
5	B210780000631	Fitting, Tee	1	
6	A210111000090	Bolt	4	
7	B210780000036	Connector, Pipe	3	




No.	Part No.	Description	Qty	Page number
8	10541251	Connector	4	
9	B230101000090	O-Ring	4	
10	A820205002445	G1/4-M16connector	2	
11	B230101000047	O-ring	4	
12	A820205000844	Fitting	2	
13	60334193	Reducer Assembly	2	3-24




No.	Part No.	Description	Qty	Page number
14	151003210051A	Hose AS	2	
15	13915446	Bulldozing shovel oil cylinder	1	3-32




No.	Part No.	Description	Qty	Page number
16	B230103003046	Rubber Hose	2	
17	151004210030A	Hose	2	
18	B230103004474	Rubber hose	2	
19	60069757	Rubber Hose	2	



No.	Part No.	Description	Qty	Page number
1	60171540	Rotor	1	
2	60171538	Housing-Swing	1	
3	60171545	Rotate sealing	11	
4	A210661000022	Steel Ball $\phi 10$ GB308-89	4	
5	60171541	Plug	4	
6	60171539	Retaining ring	1	
7	60171543	Retaining ring	1	
8	60171544	Seal-O-Ring	1	
9	60171542	Pin	1	
10	60265429	Center Swivel Joint Repairing kit	1	




No.	Part No.	Description	Qty	Page number
1	61024425	Reduction Gears	1	3-26
2	61024426	Body	1	3-28



SEAL KIT


152 — 129 130
131 139

No.	Part No.	Description	Qty	Page number
101	61024447	Body	1	
102	61024432	Cover	1	
104	61024450	Carrier 2	1	
106	61024431	B1 Gear	4	
107	61024451	B2 Gear	3	
108	61024452	S1 Gear	1	
109	61024433	S2 Gear	1	
110	61024434	Ring	4	
111	61024453	Pin	3	
113	61024435	O Snap Ring	1	
115	61024436	Thrust Collar	1	
116	61024437	Slide Seat	1	
117	61024459	Floating Seat	1	
118	61024460	O Ring	1	
119	61024448	Bearing	2	
120	61024439	Needle	92	
121	61024454	Needle	48	
122	61024455	Washer	6	
123	61024440	Snap Ring	1	
124	61024449	Snap Ring	1	
125	61024456	Snap Ring	1	
126	61024457	Snap Ring	3	
127	61024458	Spring Pin	3	
128	61024441	Snap Ring	4	
129	61024430	O Ring	1	
130	60164380	O RING	2	
131	60164387	O RING	1	
132	60164261	PLUG	2	
133	60164263	PLUG	1	
134	61024442	Hydraulic Motor	1	
137	61024461	Name Plate	1	
138	60164262	PLUG	2	
139	60164379	O RING	2	
140	60216956	THRUST WASHER	4	
141	61024443	Thrust Washer	4	
150	61024428	Carrier 2 Sub Assy	1	
151	61024427	Body Sub Assy	1	
152	61024429	Seal Kit	1	

CYLINDER BARREL
SUB ASSY

262	204	205	206
	207	208	209
	212	213	214
	221		

No.	Part No.	Description	Qty	Page number
202	61024462	Body 2	1	
203	60257722	SHAFT	1	
204	60257723	CYLINDER BARREL	1	
205	60257724	VALVE PLATE	1	
206	60257725	PISTON ASSY	9	
207	60257726	SHOE	9	
208	60257727	SHOE HOLDER	1	
209	60257728	BARREL HOLDER	1	
210	61024445	Swash Plate	1	
211	61024463	Control Piston	1	
212	60257731	PIN	3	
213	60257732	SPRING C	1	
214	60257733	RETAINER	2	
215	60257734	BEARING	1	
216	61024465	Bearing	1	
217	60164378	O RING	1	
218	60164386	O RING	2	
219	61024464	Oil Seal	1	
220	60164159	BALL	2	
221	60257737	SNAP RING	1	
222	60164376	SCREW	7	
223	61024466	Spring Pin	1	
224	60164329	PIN	1	
225	60257740	DISK PLATE	1	
226	60257741	STEEL PLATE	2	
227	60257742	BARAKE PISTON	1	
228	60257743	BARAKE SPACER	1	
229	60257744	SPRING B	10	
230	60257745	O RING	1	
231	60257746	O RING	1	
232	60257747	BACK UP RING	1	
233	60257748	BACK UP RING	1	
260	61024444	Body 2 Sub Assy	1	
261	60259580	SHAFT SUB ASSY	1	
262	60259581	CYLINDER BARREL SUB ASSY	1	





SEAL KIT (HYDRAULIC MOTOR)

330 — 217 218 219 230
231 232 233
319 321 322

BODY 1 SUB ASSY

331 — 216 223 301 302 303
304 305 306 307 308
309 310 311 312 313
314 316 317 318 319
320 321 322 323 326

No.	Part No.	Description	Qty	Page number
216	61024465	Bearing	1	
217	60164378	O RING	1	
218	60164386	O RING	2	
219	61024464	Oil Seal	1	
223	61024466	Spring Pin	1	
230	60257745	O RING	1	
231	60257746	O RING	1	
232	60257747	BACK UP RING	1	
233	60257748	BACK UP RING	1	
301	61024467	Body 1	1	
302	61024468	Spool	1	
303	61024469	Check Valve	2	
304	61024470	Seat	2	
305	61024471	Spool	1	
306	61024472	Spool B	1	
307	61024473	Spool C	1	
308	61024474	Shuttle Spool	1	
309	61024475	Spring V1	2	
310	61024476	Spring V2	2	
311	61024477	Spring V3	1	
312	61024478	Plug	2	
313	61024479	Plug	2	
314	61024480	Plug	2	
316	61024481	Plug	2	
317	61024482	Plug	8	
318	61024483	Plug	2	
319	60164387	O RING	2	
320	61024484	O Ring	2	
321	60164380	O RING	2	
322	60351718	O ring	2	
323	61024485	Plug	6	
326	61024486	Plug	2	
330	61024487	Seal Kit	1	
331	61024446	Body 1 Sub Assy	1	




No.	Part No.	Description	Qty	Page number
1	13928216	sealer package	1	


BLANK PAGE

Group 4


Work device




No.	Part No.	Description	Qty	Page number
2	13063804	Spacer	20	
16	A210804000002	Adaptor Grease	9	
18	13073008	Shaft Sleeve	2	
35	14030747	Brace piece axial pin	1	
36	A210111000199	Bolt	4	
37	A210404000004	Washer	4	
38	14036609	Lock pin	1	
39	13920595	support	1	
40	14030743	Shaft Sleeve	1	
41	13529173	Spacer	2	
42	14030744	Shaft Sleeve	3	
43	14030742	Board	1	
44	14030741	Lock pin	1	
45	A810312019061	Rigid board	1	




No.	Part No.	Description	Qty	Page number
1	10574180	Spacer	2	
2	13063804	Spacer	20	
3	60176726	Dust Ring	4	
4	13064878	Shaft Sleeve	4	
5	A210110000323	Bolt	4	
6	A210111000012	Bolt	3	
7	24000637	Washer	3	
8	A210307000031	Nut	24	
9	A210110000384	Bolt	3	
10	13916936	shaft	1	
11	13921221	light cover	1	
12	13063797	shaft	2	
13	13920283	boom	1	
14	13920316	Oil cylinder protecting board	1	
15	13915517	Work device Tube	1	4-14
16	A210804000002	Adaptor Grease	9	
17	13932055	shaft 2	1	




No.	Part No.	Description	Qty	Page number
2	13063804	Spacer	20	
3	60176726	Dust Ring	4	
4	13064878	Shaft Sleeve	4	
5	A210110000323	Bolt	4	
8	A210307000031	Nut	24	
12	13063797	shaft	2	
16	A210804000002	Adaptor Grease	9	
19	13916937	shaft	1	
20	13919908	arm	1	
28	13063799	shaft	1	




No.	Part No.	Description	Qty	Page number
2	13063804	Spacer	20	
8	A210307000031	Nut	24	
16	A210804000002	Adaptor Grease	9	
22	60176725	Dust Ring	10	
24	13064724	Shaft Sleeve	4	
26	13073232	shaft	1	
27	13072973	shaft	1	
29	A210110000014	Bolt	5	
30	13072974	shaft	1	
31	13920675	Rocker	1	
32	13920677	Left rocker	1	
33	SSY004694494	Connecting Rod Assy	1	4-24




No.	Part No.	Description	Qty	Page number
2	13063804	Spacer	20	
16	A210804000002	Adaptor Grease	9	
22	60176725	Dust Ring	10	
33	SSY004694494	Connecting RodAssy	1	4-24





No.	Part No.	Description	Qty	Page number
8	A210307000031	Nut	24	
16	A210804000002	Adaptor Grease	9	
19	13916937	shaft	1	
21	13085812	Spacer	2	
22	60176725	Dust Ring	10	
23	A2106080000086	O-ring	2	
24	13064724	Shaft Sleeve	4	
25	13072975	shaft	2	
29	A210110000014	Bolt	5	
34	13919739	Bucket	1	4-26





No.	Part No.	Description	Qty	Page number
2	13919947	steel tube assembly	1	
6	A210405000007	Washer	14	
7	A210111000093	Bolt	14	
13	13915265	Bucket Oil Cylinder	1	4-20
14	SSY004684894	pipe nip	1	
15	151004210028A	Hose	2	
16	13908742	pipe nip	4	
17	13915254	arm cylinder	1	4-22
18	13919967	steel tube assembly	1	
19	13919941	steel tube assembly	2	
20	13919945	steel tube assembly	2	
23	13908765	pipe nip	4	





No.	Part No.	Description	Qty	Page number
1	21020116	Plug	2	
3	60246980	ball valve	2	
4	13915275	Bucket cylinder assembly	1	4-18
5	A210204000218	Screw M6×55GB70.1 Grade 10.9	8	
8	13335611	Clamp	2	
9	A210404000005	Washer	2	
10	A210111000342	Bolt	2	
11	21018229	Rubber Hose	2	
12	151004210070A	Hose AS	2	
21	B210780000179	Fitting, Adapter	4	
22	24000632	Washer	8	




No.	Part No.	Description	Qty	Page number
1	13928212	sealer package	1	




No.	Part No.	Description	Qty	Page number
1	13928206	sealer package	1	



No.	Part No.	Description	Qty	Page number
1	13928198	sealer package	1	



No.	Part No.	Description	Qty	Page number
1	13920627	Connecting Rod	1	
2	13073008	Shaft Sleeve	2	
3	13064724	Shaft Sleeve	2	




No.	Part No.	Description	Qty	Page number
1	13919753	Bucket Body	1	
2	A210307000031	Nut	6	
3	A210111000024	Bolt	6	
4	12997847	left tooth	1	
5	A210307000017	Nut	6	
6	A210111000119	Bolt	6	
7	24000639	Washer	6	
8	12997848	bucket tooth	3	
9	12997846	right tooth	1	


BLANK PAGE

Group 5


driver's cab assy.




No.	Part No.	Description	Qty	Page number
1	13684419	waterproof rubber	1	
2	60341526	Cab	1	5-8
3	A210111000202	Bolt	5	
4	24000639	Washer	5	
5	14422541	Base assembly	1	5-22
6	60339991	Damper	4	
7	A210307000028	Nut	4	
8	60060553	Washer	4	





No.	Part No.	Description	Qty	Page number
9	13925158	cup seat	1	
10	24000630	Washer	13	
11	A210210000002	Screw	13	
12	24000633	Washer	34	
13	A210111000343	Bolt	26	
14	24000632	Washer	15	
15	A210204000130	Screw	2	
16	14007919	fix board	1	
17	A210204000129	Screw	6	
18	13925246	bracket of display screen	1	5-24
19	13927295	blower cover	1	
20	13603246	pendulum pedal assy	2	5-26
21	14155034	run-out footplate	1	
22	14096559	connecting board component	1	
23	13967294	running control mechanism	1	5-28
24	14184768	running valve fixed board	1	
25	13117643	base plate front sponge	2	
26	13116120	rubber protective sleeve component	1	
27	13925167	pedal	1	
28	13927274	maintenance cover	1	5-34
29	A210204000220	Screw	8	




No.	Part No.	Description	Qty	Page number
10	24000630	Washer	13	
11	A210210000002	Screw	13	
12	24000633	Washer	34	
13	A210111000343	Bolt	26	
14	24000632	Washer	15	
29	A210204000220	Screw	8	
30	60328847	Driver cab seat	1	5-36
31	60223376	Left armrest box assembly	1	5-38
32	60346062	Right armrest box assembly	1	5-40
33	A210307000055	Nut	4	
34	A210210000023	Screw	2	
35	A210405000004	Washer	2	
36	A210322000003	Nut	2	
37	14007920	fix board	1	
38	13925248	bottom board pad	1	
39	A210210000008	Screw	7	




No.	Part No.	Description	Qty	Page number
1	60349294	front-lower glass	1	
2	60349295	sealing rubber strip of front window	1	
3	60349296	front window assembly	1	5-16
4	60349297	right side glass	1	
5	60349298	right sliding window	1	
6	60349299	top glass	1	
7	60349300	top glass rubber	1	
8	60349301	back glass	1	
9	60349302	left-back side glass	1	
10	60349303	door assembly	1	5-18
11	60166748	rearview	1	5-20
12	130901000064B005	locked rebound assembly	1	
13	130901000064B006	back lock	1	




No.	Part No.	Description	Qty	Page number
14	60248548	lock of front window(right)	1	
15	60349307	lower window plate(left)	1	
16	60349308	sealing rubber of front-lower glass	1	
17	60248547	lock of front window(left)	1	
18	60248578	gas spring	2	
19	60349309	wiper arm assembly	1	
20	60023704	Antenna	1	
21	60349310	lower window plate(right)	1	
22	60349311	cabin seal rubber strip	1	
23	60349312	plastic cover of windscreen wiper	1	
24	60349313	wiper motor	1	
25	60349314	wiper arm	1	
26	60349315	wiper blade	1	




No.	Part No.	Description	Qty	Page number
27	60023703	Speaker	2	
28	60248555	wall lamp	1	
29	60166735	Pin rail	1	
30	60052666	Safety hammer	1	
31	60341344	Middle column handle	1	
32	60349317	left inner plaque	1	
33	60349316	back locker handle	1	




No.	Part No.	Description	Qty	Page number
34	60349325	radio plate	1	
35	60166732	water spraying nipple	1	
36	60349318	radio cover	1	
37	60310282	water jet assembly	1	
38	60349320	top sponge	1	
39	60349321	top sponge	1	
40	60248586	pintle of top thermal insulation sponge	12	
41	60349322	top sponge	1	
42	60349323	top sponge	1	
43	60349324	top inner plaque	1	




No.	Part No.	Description	Qty	Page number
1	60349304	lower rubber strip of front window	1	
2	60349305	glass of front window	1	
3	60349306	front window wheel	2	




No.	Part No.	Description	Qty	Page number
1	60248571	decoration plate of lock	1	
2	60248545	bottom glass of door	1	
3	60248549	lock handle from outside	1	
4	60248550	lock of door	1	
5	60248546	sliding window of door	1	
6	60248544	top glass of door	1	
7	60248551	lock catch of door	1	
8	60248575	handle indoor	1	
9	60248535	sealing rubber strip of door	1	




No.	Part No.	Description	Qty	Page number
1	A229900001398	Mirror, rear-view	1	
2	60166738	Support of rearview mirror (2)	1	
3	60166737	Support of rearview mirror (1)	1	
4	A210204000181	Screw	2	




No.	Part No.	Description	Qty	Page number
1	13924614	seat platform	1	
2	13927580	heat insulation sponge of aluminum foil	1	
3	13927581	heat insulation sponge of aluminum foil	1	
4	13927582	heat insulation sponge of aluminum foil	1	
5	13927583	heat insulation sponge of aluminum foil	1	
6	13927584	heat insulation sponge of aluminum foil	1	
7	13927671	heat insulation sponge of aluminum foil	1	
8	13927672	heat insulation sponge of aluminum foil	1	
9	13927673	heat insulation sponge of aluminum foil	1	
10	13927674	heat insulation sponge of aluminum foil	1	
11	13927675	heat insulation sponge of aluminum foil	1	
12	13927676	heat insulation sponge of aluminum foil	1	
13	13927678	heat insulation sponge of aluminum foil	1	
14	13927679	heat insulation sponge of aluminum foil	1	
15	14184966	heat insulation sponge of aluminum foil	1	
16	14333450	heat insulation sponge of aluminum foil	3	
17	14333451	heat insulation sponge of aluminum foil	1	




No.	Part No.	Description	Qty	Page number
1	14285771	bracket of display screen	1	
2	A210307000036	Nut	1	
3	14285768	bracket of display screen	1	




No.	Part No.	Description	Qty	Page number
1	13845264	installation frame	1	
2	A210414000011	Retainer Ring	1	
3	13603244	pedal	1	
4	13603245	rotating shaft	1	




No.	Part No.	Description	Qty	Page number
1	A210210000030	Screw	2	
2	60060562	Washer	2	
3	12688927	Handle, left	1	
4	12691132	Right handle	1	
5	A210111000092	Bolt	2	
6	24000633	Washer	2	
7	13603240	pedal assy	1	5-30
8	A210307000012	Nut	2	
9	14219919	right control lever	1	
10	14219752	control lever	1	
11	13603236	pedal assy	1	5-32




No.	Part No.	Description	Qty	Page number
1	13603237	front pedal	1	
2	A210414000011	Retainer Ring	1	
3	13603238	back pedal	1	
4	13603239	rotating shaft	1	




No.	Part No.	Description	Qty	Page number
1	13603234	front pedal	1	
2	A210414000011	Retainer Ring	1	
3	13603235	back pedal	1	
4	13603239	rotating shaft	1	




No.	Part No.	Description	Qty	Page number
1	13927257	front cover	1	
2	13927258	maintenance door	1	
3	60341342	Locker	2	



No.	Part No.	Description	Qty	Page number
1	130988000344A	document bag	1	
2	130988000336A	backrest assembly	1	
3	130988000340A	left cover	1	
4	130988000341A	adjust angle handle	1	
5	130988000345A	slideway limit	2	
6	130988000342A	slideway assembly	1	
7	130988000343A	skin skirt	1	
8	130988000339A	seat base assebly	1	
9	130988000337A	right cover	1	
10	130988000338A	seat belt	1	



No.	Part No.	Description	Qty	Page number
1	60259927	hand rail	1	
2	60259923	hand rail limit	1	
3	60259919	left armrest box upper cover	1	
4	60259920	upper cover anchor	1	
5	60292211	left armrest box framework	1	
6	60259922	left armrest box left shell	1	
7	60259925	handle lever	1	
8	60259924	handle	1	
9	60309855	gas spring	1	
10	60259921	left armrest box right shell	1	
11	60250079	journey switch	1	



No.	Part No.	Description	Qty	Page number
1	60259932	bulldozing shovel bar	1	
2	60259923	hand rail limit	1	
3	60306446	rocker switch	1	
4	60306447	rocker switch	1	
5	60259936	right armrest box upper cover	1	
6	60259920	upper cover anchor	1	
7	60259930	right armrest box left shell	1	
8	60259937	right armrest box right shell	1	
9	60259936	right armrest box upper cover	1	
10	60306443	rocker switch	1	
11	60259927	hand rail	1	
12	60349326	arm box screen cover	1	


BLANK PAGE

Group 6


general assembly of covering parts



No.	Part No.	Description	Qty	Page number
1	13938363	right door assy	1	
2	A210111000342	Bolt	1	
3	60060565	Washer	28	
4	SSY004596719	lock catch	1	
5	A210111000343	Bolt	28	
6	13938368	front engine hood assy	1	6-4
7	14138971	Right engine hood sealant strip	1	
8	13938371	supporting lever	1	
9	A210491000007	Pin	4	
10	A210307000036	Nut	3	
11	A810502019056	Setscrew	3	
12	24000633	Washer	5	
13	14151076	Sealing strip	1	
14	13003583	wind hook component	1	
15	14146001	Rear engine hood sealant strip	1	
16	13938344	assembly of rear hood	1	6-6
17	A210491000120	Washer	3	
18	A210111000012	Bolt	3	
19	13088475	left rubber strip	1	
20	13938376	lock catch	1	
21	13938373	connecting board	1	
22	14138972	Left engine hood sealant strip	1	
23	13938343	left door assy	1	
24	SSY004596720	sponge	1	
25	14039767	left wall panel assy	1	
26	13938317	right wall panel	1	
27	14351881	sealing sponge	1	
28	A210491000121	Washer	8	
29	A210111000204	Bolt	8	
30	13938338	bracket assy	1	



No.	Part No.	Description	Qty	Page number
1	13938369	front engine hood weldment	1	
2	13328071	lock sleeve	1	
3	60354875	Bonnet lock	1	
4	24000633	Washer	2	
5	A210111000342	Bolt	2	




No.	Part No.	Description	Qty	Page number
1	60342357	door lock	1	
2	13938352	rear hood	1	
3	24000632	Washer	4	
4	23000169	Nut	4	
5	13938315	hinge assy	1	
6	A210491000120	Washer	2	
7	A210111000197	Bolt	2	


BLANK PAGE

Group 7


Electrical assembly drawing



No.	Part No.	Description	Qty	Page number
1	60066402	Battery	1	
2	60012803	Power Supply Harness	2	
3	60060546	Washer	5	
4	A210111000012	Bolt	5	
5	60193169	Power line	1	
6	60212612	DC contactor	1	
7	60211509	Horn	1	
8	60012805	Cable, Battery	1	
9	14050228	DianYuanXian	1	
10	60241333	Batterie Switch	1	
11	14039989	switch support	1	
12	60013322	Terminal Assembly,Battery,Positive	1	
13	60013321	Terminal Assembly,Battery,Negative	1	
14	60086354	Clamp	2	
15	13927585	Display harness	1	
16	14056054	Sany Encourage Control Display	1	
17	60143661	Work Lamp	3	
18	60237043	Alarm lamp	1	
19	60222807	Charger	1	
20	60050766	Contact Module	1	
21	B240200000059	Emergency Switch	1	
22	61030659	Radio	1	



No.	Part No.	Description	Qty	Page number
23	13919779	Driver's Cab Harness	1	
24	60202078	Cluster Fixed Lace	2	
25	13919755	Control Switch Harness	1	
26	60218598	Ignition switch	1	
27	12824424	Integrated box	1	7-6
28	24002251	Screw	2	
29	A210210000008	Screw	4	
30	A2102100000023	Screw	3	
31	A2413000000059	Fuse Housing	1	
32	A2102100000030	Screw	4	
33	24000630	Washer	4	




No.	Part No.	Description	Qty	Page number
1	60215655	Intermediate Relay	1	
2	60215653	Intermediate Relay	7	
3	60215505	fuse	2	
4	60215506	fuse	5	
5	60215507	fuse	2	
6	60215508	fuse	1	
7	60215509	fuse	1	
8	60215510	fuse	1	


BLANK PAGE

Group 8


Coating




驾驶室右玻璃/right glass in cab




驾驶室左玻璃/left glass in cab



No.	Part No.	Description	Qty	Page number
1	10124614	Caution plate of bucket rod	2	
2	13792522	SY16 left movable arm marking	1	
3	12052087	Mark Diagram of Hook Point	4	
4	A820603000246	Forward direction indication	2	
5	13166446	Fixed loading spot mark	4	
6	13923407	Machine Model Marking	1	
7	A820601000014	Control indicating board of bulldozing shovel	1	
8	12052088	Front window lock caution board	1	
9	12033806	Safety sign - "Beware of fire	1	
10	13964881	Slewing bearing oil filler mark	1	
11	13411269	Lifting Mark	1	
12	13834945	Name Plate	1	
13	13155987	Leading switch mark	1	
14	13507562	Control instruction	1	
15	14414127	decal	1	
16	13944319	Lift capability meter	1	
17	A820601990927	Decal, unlock	1	
18	13834946	Name Plate	1	
19	13146624	Noise marker	1	





No.	Part No.	Description	Qty	Page number
20	13507828	Oil level label	1	
21	13922463	Machine Model Marking	1	
22	13792523	SY16 right movable arm marking	1	
23	13166419	Safety exit lable	1	
24	A820601991049	Counterweight warning board	2	
25	13923421	Counterweight left reflective coating	1	
26	13507584	High temperature warning	1	
27	13507819	no open flame	1	
28	13923425	Counterweight right reflective coating	1	
29	13507568	Oil-water separator drain instruction	1	
30	13507822	Counter rotating rollers	1	
31	13507565	Fan warning	1	
32	13507780	One way/two way valve	1	
33	13922459	Counterweight Marking	1	
34	13507855	toxic	1	
35	14208194	Coating	1	
36	13507743	Read manual	1	
37	13504946	Emergency Stop Switch	1	
38	14373382	FOPS& TOPS Card	1	
39	13156069	Foot pedal mark	1	
40	13507746	Seat safety caution board	1	




散热器/Radiator

油箱/Fuel tank



蓄电池/Accumulator














No.	Part No.	Description	Qty	Page number
41	12033810	No trample Nameplate	1	
42	13340334	Oil level label	1	
43	13509503	be care of steam	1	
44	13166425	Fuel tank indicator	1	
45	13272748	Hydraulic oil tank indicative board	1	
46	13507767	Power sign	1	


BLANK PAGE

Group 9


Attached accessories



No.	Part No.	Description	Qty	Page number
1	11826337	SANY excavator maintenance and guarantee(English)	1	
2	60041997	Accessories Box	1	
3	60027935	oil filter	1	
4	60273107	fuel oil filter	1	
5	60123506	Main cartridge of air cleaner	1	
6	14042474	Accompanying tools	1	9-4
7	14155494	SY26 Loading Information	1	
8	14155497	SY26 Operation Manual	1	
9	14155499	SY26 Maintenance Manual	1	
10	14532509	Engine Drawing Volume for SY26C3Y5LU(EU)	1	
11	14532534	Drawing volume of parts SY26C3Y5LU(EU)	1	



No.	Part No.	Description	Qty	Page number
1	A260401030028	Double-ended spanner	1	
2	A260401030007	Spanner, double-ended	1	
3	A260401030100	Wrench, box end	1	
4	60001295	Socket	1	
5	B260401090024	Spanner, belt	1	
6	A260401030005	Spanner, double-ended	1	
7	A260401040004	Spanner, adjustable	1	
8	A260401010025	Socket	1	
9	A260401010063	Socket	1	
10	A260401010027	Socket	1	
11	A260401010051	Socket 24×12.5GB3390.1	1	
12	A260401010029	Socket	1	
13	A260401090010	Wrench ratchet	1	
14	A260401010092	Connecting rod	1	
15	A260401020009	Wrench, allen	1	
16	A260401020010	Wrench, allen	1	
17	A260401020011	Wrench, Allen 8RGB5356	1	
18	A260401020004	Wrench, allen	1	
19	A290000000155	Toolbox, portable	1	9-6
20	B260409000015	High pressure grease gun	1	



No.	Part No.	Description	Qty	Page number
1	60153777	Upper cover	1	
2	60153697	Handle	1	
3	60153693	Latch	2	
4	60153713	Base	1	
5	60153827	Tray	1	
6	60153665	Support, left	1	
7	60153654	Support, right	1	

BLANK PAGE

Appendix A Alphabetical Index

Accessories Box 60041997	9-3
Accompanying tools 14042474	9-3
Accumulator connector 61016948	2-141
Accumulator 61016947	2-141
Adapter, relay A820205000944	2-93
Adaptor Grease A210804000002	2-7, 3-5, 4-3, 4-5, 4-7, 4-9, 4-11, 4-13
adjust angle handle 130988000341A	5-37
Alarm lamp 60237043	7-3
Angle sealing strip 60205959	3-11
Antenna 60023704	5-11
Arm Assy 61024033	2-53
arm box screen cover 60349326	5-41
arm cylinder 13915254	4-15
Arm Spool 61024038	2-73
Arm Valve Block 61024048	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
arm 13919908	4-7
assembly of rear hood 13938344	6-3
Attached accessories 14532950	1-3
B1 Gear 61024431	3-27
B2 Gear 61024451	3-27
back glass 60349301	5-9
back lock 130901000064B006	5-9
back locker handle 60349316	5-13
back pedal 13603235	5-33
back pedal 13603238	5-31
BACK UP RING 60257747	3-29, 3-31
BACK UP RING 60257748	3-29, 3-31
Back Up Ring 61024537	2-83
backrest assembly 130988000336A	5-37
ball valve 60246980	2-19, 4-17
BALL 60164159	3-29
Ball 61016950	2-141
BARAKE PISTON 60257742	3-29
BARAKE SPACER 60257743	3-29
BARREL HOLDER 60257728	3-29
Barrel Holder 61024520	2-81
Base 60153713	9-7
Base assembly 14422541	5-3
base plate front sponge 13117643	5-5
Batterie Switch 60241333	7-3
Battery 60066402	7-3
be care of steam 13509503	8-7
Bearing Ring 60248025	3-9
BEARING 60257734	3-29
Bearing 61024421	2-81
Bearing 61024424	2-81
Bearing 61024448	3-27
Bearing 61024465	3-29, 3-31
Bearing 61024494	2-85
Bearing 61024495	2-85
blower cover 13927295	5-5
Blower 60330156	2-173
Board 14030742	4-3
Body 1 Sub Assy 61024446	3-31
Body 1 61024467	3-31
Body 2 Sub Assy 61024444	3-29
Body 2 61024462	3-29
body cylinder 60280435	3-9
Body Group 61024420	2-81
Body of valve 60171572	2-147
Body of valve 60171579	2-153, 2-155
Body Sub Assy 61024427	3-27
Body 60290357	2-165

Body 60290358	2-143
Body 61024426	3-25
Body 61024447	3-27
Body 61024489	2-85
Body 61024510	2-81
Body 61024531	2-83
Bolt A210111000092	5-29
Bolt A210111000202	5-3
Bolt A210111000204	6-3
Bolt, socket head 61025254	2-151
Bolt 21005237	3-3
Bolt 60225886	2-99
Bolt 60290341	2-165
Bolt A210110000014	3-5, 4-9, 4-13
Bolt A210110000323	2-7, 3-5, 4-5, 4-7
Bolt A210110000384	4-5
Bolt A210111000012	3-5, 3-7, 4-5, 6-3, 7-3
Bolt A210111000024	4-27
Bolt A210111000090	3-15
Bolt A210111000093	4-15
Bolt A210111000119	4-27
Bolt A210111000197	6-7
Bolt A210111000199	4-3
Bolt A210111000206	3-9
Bolt A210111000209	3-3
Bolt A210111000240	2-171
Bolt A210111000321	2-11
Bolt A210111000323	2-5, 2-13
Bolt A210111000342	4-17, 6-3, 6-5
Bolt A210111000343	2-9, 2-43, 2-89, 3-3, 3-7, 5-5, 5-7, 6-3
Bolt A210111000442	3-3
Bonnet lock 60354875	6-5
Boom Assy 61024032	2-53
Boom Spool 61024039	2-71
Boom Swing Assy 61024029	2-53
Boom Swing Spool 61024041	2-65
boom 13920283	4-5
bottom board pad 13925248	5-7
bottom cover plate 13040450	3-7
bottom glass of door 60248545	5-19
Brace piece axial pin 14030747	4-3
bracket assy 13938338	6-3
bracket of display screen 13925246	5-5
bracket of display screen 14285768	5-25
bracket of display screen 14285771	5-25
bracket 14172251	2-5
Brake Piston Group 61024422	2-81
Brake Piston 61024528	2-81
Breather Valve 60237031	2-25
Bucket Assy 61024034	2-53
Bucket Body 13919753	4-27
Bucket cylinder assembly 13915275	4-17
Bucket Oil Cylinder 13915265	4-15
Bucket Spool 61024037	2-75
bucket tooth 12997848	4-27
Bucket 13919739	4-13
bulldozing shovel bar 60259932	5-41
Bulldozing shovel oil cylinder 13915446	3-19
Bulldozing shovel oil cylinder 13915468	2-31
Bulldozing shovel 13919736	3-13
BUSHING 60221102	2-153, 2-155
Cab 60341526	5-3
cabin seal rubber strip 60349311	5-11
Cable, Battery 60012805	7-3
Cap 60290377	2-143
Cap 61024534	2-83
Carrier 1 61024498	2-85

Carrier 2 Sub Assy 61024428	3-27
Carrier 2 61024450	3-27
Carrier 2 61024504	2-85
Caution plate of bucket rod 10124614	8-3
Center Swivel Joint Repairing kit 60265429	3-23
Center Swivel Joint 60022417	3-15
Charger 60222807	7-3
Check Valve 61024054	2-57, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
Check Valve 61024469	3-31
Check Valve 61024512	2-81
Clamp 13335611	4-17
Clamp 13919943	2-31
Clamp 60086354	2-9, 7-3
Cluster Fixed Lace 60202078	7-5
Coating 14000776	1-3
Coating 14208194	8-5
Coil 61016946	2-141
Combination Running frame 13922934	3-3
Compensator spool 61024045	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
Cone 61016956	2-141
connecting board component 14096559	5-5
connecting board 13938373	6-3
Connecting Rod 13920627	4-25
Connecting rod 61026664	2-153, 2-155
Connecting rod A260401010092	9-5
Connecting Rod Assy SSY004694494	4-9, 4-11
Connection Shaft 61008472	2-49
Connection 60290332	2-165
Connector Pipe B210780000827	2-89
Connector, Pipe B210780000036	2-23, 3-15
Connector, pipe B210780000143	2-101
Connector, pipe B210780000177	2-13
Connector, Pipe B210780000180	2-13, 2-107, 2-159, 2-167
Connector, Pipe B210780000232	2-23, 2-105, 3-15
Connector 10165802	2-25
Connector 10541251	2-157, 3-17
Connector 12978957	2-13
Connector 12978991	2-105
connector 13053059	2-13, 2-159, 2-167
Connector 13603282	2-23
Connector 61008467	2-49
Connector 61026661	2-153, 2-155
Connectorpipe B210780000174	3-15
Contact Module 60050766	7-3
Control indicating board of bulldozing shovel A820601000014	8-3
Control insturction 13507562	8-3
control lever 14219752	5-29
Control piston 60290334	2-165
Control Piston 61024463	3-29
Control Rod 60290339	2-165
Control Switch Harness 13919755	7-5
Copper sleeve 60290368	2-143, 2-149
Counter rotating rollers 13507822	8-5
Counterbalancing Sring 61008465	2-49
counterweight assembly 13940022	2-5
Counterweight left reflective coating 13923421	8-5
Counterweight Marking 13922459	8-5
Counterweight right reflective coating 13923425	8-5
Counterweight warning board A820601991049	8-5
counterweight 13913236	2-11
Cover board 10597771	3-5
cover plate 12996227	2-9
cover plate 14518215	3-3
Cover 61008440	2-49
Cover 61024432	3-27
Cross recessed pan head tapping screws 60141820	2-147

cup seat 13925158	5-5
CYLINDER BARREL SUB ASSY 60259581	3-29
CYLINDER BARREL 60257723	3-29
Cylinder Barrel 61024515	2-81
Cylinders Block 61008464	2-49
Damper 60339991	5-3
DC contactor 60212612	7-3
Decal, unlock A820601990927	8-3
decal 14414127	8-3
decoration plate of lock 60248571	5-19
DianYuanXian 14050228	7-3
DISK PLATE 60257740	3-29
Disk Plate 61024529	2-81
Display harness 13927585	7-3
document bag 130988000344A	5-37
door assembly 60349303	5-9
door lock 60342357	6-7
Double-ended spanner A260401030028	9-5
Dowel Pin Casehardened 61008478	2-49
Dowel Pin Casehardened 61008480	2-49
Dowel Pin Elastic 61008477	2-49
Dowel Pin Elastic 61008479	2-49
Dowel 61008481	2-49
Dozer Assy 61024025	2-53
Dozer Blade SSY004698999	3-5
Dozer Spool 61024043	2-57
drainage tube 13494001	2-5
Drawing volume of parts SY26C3Y5LU(EU) 14532534	9-3
Driver cab seat 60328847	5-7
driver's cab assy. 13927865	1-3
Driver's Cab Harness 13919779	7-5
Driving wheel 13891396	3-3
Dust Cover 60290375	2-143
Dust Ring 60176725	3-5, 4-9, 4-11, 4-13
Dust Ring 60176726	4-5, 4-7
Dust Ring 60248024	3-9
Eccentric Drive Torque Limiter 61008461	2-49
Electrical assembly drawing 14136941	1-3
Electromagnetic reversal valve 60342181	2-87
Electromagnetic valve 61016945	2-141
Emergency Stop Switch 13504946	8-5
Emergency Switch B240200000059	7-3
End Assy 61024035	2-53
End Cover 61024036	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
End Valve Block 61024049	2-77
Engine Drawing Volume for SY26C3Y5LU(EU) 14532509	9-3
Fan warning 13507565	8-5
Filter core 60114999	2-43
Filter, hydraulic tank breather 60174894	2-45
Filter, pilot AS B229900000063	2-89
FILTER 60258113	2-81
Filtercore 60167908	2-43
Fitting A820205000858	2-7
Fitting A820205000940	2-101, 2-103, 2-157
Fitting Elbow B210780000024	2-13, 2-17, 2-19, 2-23, 2-89, 2-101, 2-107, 2-157
Fitting Elbow B210780000418	2-87, 2-91, 2-93, 2-101, 2-107
Fitting Tee L-Shape B210780000016	2-13
Fitting, Adapter, Flange 21011030	2-15
Fitting, Adapter A229900010390	2-21
Fitting, Adapter B210780000176	2-87, 2-91, 2-107
Fitting, Adapter B210780000179	2-13, 2-19, 4-17
Fitting, Bulkhead Connector B210780000115	2-163
Fitting, Elbow B210780000029	2-15
Fitting, Elbow B210780000636	2-23
Fitting, Elbow B210780001310	2-13

Fitting, tee, L-shape B210780000019	2-103
Fitting, Tee, L-shape B210780000170	2-87, 2-91, 2-93, 2-161
Fitting, Tee B210780000631	3-15
Fitting, Tee B210780001007	2-21
Fitting A820205000844	3-17
Fitting B210780000172	2-91
Fitting B210780001045	2-91, 2-93
fix board 14007919	5-5
fix board 14007920	5-7
Fixed loading spot mark 13166446	8-3
Fixed plate 60171644	2-145
Flange, Split B210780000244	2-15
FLANGE 60221097	2-153, 2-155
Floating Seat 61024459	3-27
Flow Compensator 61008437	2-47
Flow Compensator 61008439	2-47
Foot pedal mark 13156069	8-5
FOPS& TOPS Card 14373382	8-5
Forward direction indication A820603000246	8-3
front cover 13927257	5-35
front engine hood assy 13938368	6-3
front engine hood weldment 13938369	6-5
front pedal 13603234	5-33
front pedal 13603237	5-31
front window assembly 60349296	5-9
Front window lock caution board 12052088	8-3
front window wheel 60349306	5-17
front-lower glass 60349294	5-9
fuel oil filter 60273107	9-3
Fuel tank indicator 13166425	8-7
Fuse Housing A241300000059	7-5
fuse 60215505	7-7
fuse 60215506	7-7
fuse 60215507	7-7
fuse 60215508	7-7
fuse 60215509	7-7
fuse 60215510	7-7
G1/2(ED)-M26-L65 connector 11147213	2-13, 2-21
G1/4-M14 Connector 13623064	2-93
G1/4-M16connector A820205002445	3-17
G1/4(ED)-M14Connector 12877195	2-7
G3/8-M18 connector A820205002389	2-17, 2-103
gas spring 60248578	5-11
gas spring 60309855	5-39
Gauge, sight glass A250100000174	2-43
Gear B1 61024499	2-85
Gear B2 61024505	2-85
Gear Group 1 61024414	2-85
Gear Group 2 61024415	2-85
general assembly of covering parts 14139093	1-3
glass of front window 60349305	5-17
guide wheel assy. 13891370	3-3
hand rail limit 60259923	5-39, 5-41
hand rail 60259927	5-39, 5-41
handle indoor 60248575	5-19
handle lever 60259925	5-39
Handle, left 12688927	5-29
Handle 60153697	9-7
handle 60259924	5-39
Handle 61026662	2-155
Handle 61026663	2-153
heat insulation sponge of aluminum foil 13927580	5-23
heat insulation sponge of aluminum foil 13927581	5-23
heat insulation sponge of aluminum foil 13927582	5-23
heat insulation sponge of aluminum foil 13927583	5-23
heat insulation sponge of aluminum foil 13927584	5-23
heat insulation sponge of aluminum foil 13927671	5-23

heat insulation sponge of aluminum foil 13927672	5-23
heat insulation sponge of aluminum foil 13927673	5-23
heat insulation sponge of aluminum foil 13927674	5-23
heat insulation sponge of aluminum foil 13927675	5-23
heat insulation sponge of aluminum foil 13927676	5-23
heat insulation sponge of aluminum foil 13927678	5-23
heat insulation sponge of aluminum foil 13927679	5-23
heat insulation sponge of aluminum foil 14184966	5-23
heat insulation sponge of aluminum foil 14333450	5-23
heat insulation sponge of aluminum foil 14333451	5-23
heater assembly SY16 60312888	2-171
High pressure grease gun B260409000015	9-5
High temperature warning 13507584	8-5
hinge assy 13938315	6-7
holding valve 60240905	2-157
Hoop A210855000024	2-27
Horn 60211509	7-3
Hose AS 151003210051A	3-19
Hose AS 151004210070A	4-17
Hose AS B230103000932	2-113
Hose Assembly B230103002263	2-113
Hose B230103003389	2-37
Hose ring hoop 21053360	2-5
Hose 151003210023A	2-35
Hose 151003210024A	2-31
Hose 151004210028A	4-15
Hose 151004210029A	2-33, 2-39
Hose 151004210030A	3-21
Hose 151004210031A	2-37, 2-163
Hose 151006210006A	2-39
Hose B230103000995	2-119
hose B230103002042	2-7
Hose B230103007052	2-7
Housing-Swing 60171538	3-23
Hydraulic Main Pipeline SSY004640651	2-3
Hydraulic Motor 61024419	2-79
Hydraulic Motor 61024442	3-27
hydraulic oil tan 13920373	2-43
Hydraulic oil tank indicative board 13272748	8-7
Ignition switch 60218598	7-5
Inlet Assy 61024024	2-53
Inlet Valve Block 61024047	2-55
Inner Ring 13863791	3-11
installation frame 13845264	5-27
installation plate 60280438	3-9
Integrated box 12824424	7-5
Intermediate Relay 60215653	7-7
Intermediate Relay 60215655	7-7
Internal Gear 61024491	2-85
Joint valve 60330154	2-173
Joint 61026667	2-153, 2-155
journey switch 60250079	5-39
Joystick assembly 60290374	2-143
Kit, seal 60164336	2-81
Kit, seal 60258139	2-83
Latch 60153693	9-7
Leading switch mark 13155987	8-3
Left armrest box assembly 60223376	5-7
left armrest box framework 60292211	5-39
left armrest box left shell 60259922	5-39
left armrest box right shell 60259921	5-39
left armrest box upper cover 60259919	5-39
left cover 130988000340A	5-37
left door assy 13938343	6-3
Left engine hood sealant strip 14138972	6-3
left inner plaque 60349317	5-13
Left rocker 13920677	4-9

left rubber strip 13088475	6-3
left tooth 12997847	4-27
left wall panel assy 14039767	6-3
left-back side glass 60349302	5-9
lengthening adaptor 14210440	2-15
Lift capability meter 13944319	8-3
Lifting Mark 13411269	8-3
light cover 13921221	4-5
lock catch of door 60248551	5-19
lock catch 13938376	6-3
lock catch SSY004596719	6-3
lock handle from outside 60248549	5-19
Lock Nut 61008600	2-47
Lock Nut 61008601	2-47
lock of door 60248550	5-19
lock of front window(left) 60248547	5-11
lock of front window(right) 60248548	5-11
Lock pin 13036922	3-5
Lock pin 13036961	2-7, 3-5
Lock pin 14030741	4-3
Lock pin 14036609	4-3
lock sleeve 13328071	6-5
locked rebound assembly 130901000064B005	5-9
Locker 60341342	5-35
lower rubber strip of front window 60349304	5-17
lower window plate(left) 60349307	5-11
lower window plate(right) 60349310	5-11
LS Flow Valve 61024053	2-55
Machine Model Marking 13922463	8-5
Machine Model Marking 13923407	8-3
Main cartridge of air cleaner 60123506	9-3
Main Valve Repair Kit 61024073	2-53
maintenance cover 13927274	5-5
maintenance door 13927258	5-35
mandrel 60280434	3-9
Mark Diagram of Hook Point 12052087	8-3
Mhste Housing 61016944	2-141
Middle column handle 60341344	5-13
Mirror, rear-view A229900001398	5-21
Motor cover 13919848	3-7
Multiple valve 60338118	2-13
Name Plate 13834946	8-3
Name Plate 13834945	8-3
Name Plate 61024461	3-27
Nameplate 60171658	2-147
Needle 61024439	3-27
Needle 61024454	3-27
Needle 61024500	2-85
Needle 61024506	2-85
no open flame 13507819	8-5
No trample Nameplate 12033810	8-7
Noise marker 13146624	8-3
Nut A210307000036	5-25, 6-3
Nut 23000169	6-7
Nut 60259205	2-153, 2-155
Nut 60290340	2-165
Nut 61008447	2-47
Nut 61020153	2-53
Nut 61026665	2-153, 2-155
Nut A210307000001	2-5, 2-7
Nut A210307000012	2-143, 5-29
Nut A210307000015	2-143, 2-149
Nut A210307000017	4-27
Nut A210307000028	5-3
Nut A210307000031	3-5, 4-5, 4-7, 4-9, 4-13, 4-27
Nut A210307000055	5-7
Nut A210322000003	5-7

O RING 60164378	2-81, 3-29, 3-31
O RING 60164379	2-81, 3-27
O RING 60164380	2-83, 3-27, 3-31
O RING 60164381	2-83
O RING 60164384	2-83
O RING 60164385	2-83
O RING 60164386	3-29, 3-31
O RING 60164387	3-27, 3-31
O RING 60257745	2-81, 3-29, 3-31
O RING 60257746	3-29, 3-31
O ring 60290337	2-165
O ring 60351718	3-31
O Ring 61024057	2-55, 2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
O Ring 61024058	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
O Ring 61024059	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
O Ring 61024417	2-85
O Ring 61024430	3-27
O Ring 61024460	3-27
O Ring 61024484	3-31
O Snap Ring 61024435	3-27
O-ring 21000123	2-165
O-ring 21019042	2-143, 2-149
O-ring 21029124	2-165
O-Ring 61008453	2-49
O-Ring 61008454	2-47
O-Ring 61008455	2-49
O-Ring 61008456	2-47
O-Ring 61016949	2-141
O-Ring 61016952	2-141
O-Ring 61016957	2-141
O-ring 61020169	2-55
O-ring 61020176	2-55, 2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
O-ring 61020201	2-59, 2-61
O-ring A210608000007	2-143, 2-149, 2-165
O-ring A210608000018	2-43
O-ring A210608000073	2-147
O-ring A210608000077	2-15, 2-25
O-ring A210608000086	4-13
O-ring A210609000095	2-147
O-ring A880802040016	2-43
O-ring B230101000047	2-93, 2-101, 2-103, 2-157, 3-17
O-ring B230101000049	2-17, 2-103, 2-143, 2-149
O-Ring B230101000090	2-157, 3-17
O-ring B230101000356	2-43
O-ring B230101000679	2-165
Oil cylinder protecting board 13920316	4-5
oil filter 60027935	9-3
Oil level label 13340334	8-7
Oil level label 13507828	8-5
Oil Seal 61024464	3-29, 3-31
Oil Seal 61024496	2-85
Oil source valve repair kit 61016964	2-141
Oil suction steel tube 13919911	2-15
Oil suction steel tube 13919934	2-25
oil tube 13919859	2-25
Oil-water separator drain instruction 13507568	8-5
One way/two way valve 13507780	8-5
Option Spool 61024040	2-67, 2-69
Option1 Assy 61024030	2-53
Option2 Assy 61024031	2-53
Outer Ring 13863860	3-11
pedal assy 13603236	5-29
pedal assy 13603240	5-29
pedal 13603244	5-27
pedal 13925167	5-5

pendulum pedal assy 13603246	5-5
Pilot pipeline SSY004640655	2-3
Pilot valve 60247936	2-95
Pilot valve 60352305	2-109
Pilot valve 60352306	2-109
Pilot-control Valve 60129665	2-93
Pilot-control Valve 60281974	2-97
Pin rail 60166735	5-13
Pin 60012591	3-11
Pin 60078066	3-11
PIN 60164322	2-81
PIN 60164329	3-29
Pin 60171542	3-23
Pin 60171675	2-145
Pin 60171676	2-145
PIN 60257731	3-29
Pin 60290370	2-143, 2-149
Pin 61024453	3-27
Pin 61024497	2-85
Pin 61024522	2-81
Pin 61024525	2-81
Pin A210491000007	6-3
Pinion Gear Group 61024413	2-85
pintle of top thermal insulation sponge 60248586	5-15
Pipe connector 21011540	2-93
Pipe connector 21053567	2-13
Pipe connector 23904681	2-87, 2-89, 2-91, 2-93, 2-95, 2-97, 2-99, 2-157, 2-159, 2-167
Pipe connector 60136966	2-87, 2-89, 2-91, 2-93
Pipe connector 60140964	2-89, 2-97, 2-99
Pipe connector 60175301	2-93, 2-95, 2-159
Pipe connector A229900010160	2-7, 2-101
Pipe connector B210780000014	2-93, 2-99, 2-159
pipe nip 13908742	4-15
pipe nip 13908765	4-15
pipe nip SSY004684894	4-15
Pipeline Of Arm 14542145	2-3
Pipeline of Boom(with maintaining valve) 14541994	2-3
PISTON ASSY 60257725	3-29
Piston cover 60290336	2-165
Piston Rod 60290338	2-165
Piston Rod 60290367	2-143, 2-149
Piston 60290343	2-165
Piston 61008471	2-49
Piston 61008476	2-47
Piston 61024517	2-81
Piston 61024533	2-83
Pistons Guide Plate 61008469	2-49
Pistons Spring 61008466	2-49
plastic cover of windscreen wiper 60349312	5-11
plate 13061324	2-43
plate 13919944	2-31
plate 13920376	2-43
Plate 61024526	2-81
PLliger Pump Repair Kit 61008486	2-49
Plug 21020116	4-17
Plug 60147943	2-147
PLUG 60164261	3-27
PLUG 60164262	3-27
PLUG 60164263	3-27
Plug 60171541	2-145, 3-23
Plug 60290333	2-165
Plug 60290346	2-165
Plug 60290350	2-165
Plug 60290351	2-165
Plug 60290356	2-165
Plug 61008482	2-49

Plug 61008483	2-47
Plug 61008484	2-47
Plug 61008485	2-49
Plug 61016953	2-141
Plug 61016960	2-141
Plug 61016963	2-141
Plug 61020174	2-55
Plug 61024060	2-77
Plug 61024061	2-77
Plug 61024062	2-59, 2-61
Plug 61024063	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
Plug 61024064	2-55
Plug 61024478	3-31
Plug 61024479	3-31
Plug 61024480	3-31
Plug 61024481	3-31
Plug 61024482	3-31
Plug 61024483	3-31
Plug 61024485	3-31
Plug 61024486	3-31
Plug 61024513	2-81
Plug B210780000609	2-23, 3-15
Plunger AS 60171687	2-153, 2-155
plunger assembly 60171686	2-147
Plunger Pump 60338255	2-15
Poppet 60290345	2-165
Poppet 61024532	2-83
Power line 60193169	7-3
Power sign 13507767	8-7
Power Supply Harness 60012803	7-3
power system 14138545	1-3
Pre-Load Callar 61024493	2-85
Pressure relay B240700000221	2-93
Pressure Sensor 60114799	2-91
Proportional Electromagnetic Valve 60281431	2-99
Protective Sleeve 11133774	3-7
Protective Sleeve 11133805	3-7
Protective sleeve 11225694	2-9
Protective sleeve 13036166	2-171
Protective sleeve 60171688	2-145
Pump Body 61008475	2-49
pumping 13863863	3-11
Push rod assembly 60171672	2-145
radio cover 60349318	5-15
radio plate 60349325	5-15
Radio 61030659	7-3
Read manual 13507743	8-5
Rear engine hood sealant strip 14146001	6-3
rear hood 13938352	6-7
rearview 60166748	5-9
Reducer Assembly 60334193	3-17
Reducer Assembly 60334194	2-17
Reducer hosing 61016955	2-141
Reducer spool 61016954	2-141
Reduction Gears 61024412	2-79
Reduction Gears 61024425	3-25
Refiller Valve 60248022	3-9
Relief Valve 61024070	2-57, 2-65, 2-69, 2-71, 2-73, 2-75
Relief Valve 61024072	2-67
Relief Valve 61024488	2-81
Repair kit,handle 61026668	2-155
Repair kit,handle 61026669	2-153
Repair Kit 150588000006	2-143
Restrictor 61024065	2-61
Retainer ring 60290354	2-165
Retainer Ring A210414000003	2-143, 2-149
Retainer Ring A210414000011	5-27, 5-31, 5-33

RETAINER 60257733	3-29
Retaining ring 60171539	3-23
Retaining ring 60171543	3-23
Retaining ring 60171550	2-145
Retaining ring 60171551	2-153, 2-155
Retaining ring 60171553	2-153, 2-155
revolving frame 13937753	2-5
Right armrest box assembly 60346062	5-7
right armrest box left shell 60259930	5-41
right armrest box right shell 60259937	5-41
right armrest box upper cover 60259936	5-41
right control lever 14219919	5-29
right cover 130988000337A	5-37
right door assy 13938363	6-3
Right engine hood sealant strip 14138971	6-3
Right handle 12691132	5-29
right side glass 60349297	5-9
right sliding window 60349298	5-9
right tooth 12997846	4-27
right wall panel 13938317	6-3
Rigid board A810312019061	4-3
Ring 1 61024503	2-85
Ring 2 61024509	2-85
Ring Retaining 61024418	2-85
Ring Seal 61024492	2-85
Ring 61008457	2-47
Ring 61008458	2-49
Ring 61008459	2-47
Ring 61024434	3-27
rocker switch 60306443	5-41
rocker switch 60306446	5-41
rocker switch 60306447	5-41
Rocker 13920675	4-9
Roller Bearing 61008441	2-49
Roller Bearing 61008442	2-49
Rotate sealing 60171545	3-23
rotating shaft 13603239	5-31, 5-33
rotating shaft 13603245	5-27
Rotor 60171540	3-23
Rubber crawler 60343115	3-3
Rubber Hose 1SN6-DKOL-DKOL90-440 A831213044000	2-7, 2-117
Rubber hose 13182689	2-31, 2-167
Rubber hose 151004210027A	2-41
Rubber Hose 21018229	4-17
Rubber Hose 21020859	2-111
Rubber Hose 21054224	2-115
Rubber Hose 60018916	2-119
Rubber Hose 60069757	3-21
Rubber hose 60101296	2-41
Rubber Hose 60120208	2-129
Rubber Hose 60120209	2-123, 2-125
Rubber Hose 60120210	2-129
Rubber Hose 60120211	2-135
Rubber Hose 60120212	2-161, 2-169
Rubber Hose 60120213	2-123, 2-169
Rubber Hose 60120214	2-139
Rubber Hose 60120215	2-129
Rubber Hose 60120217	2-139, 2-161
Rubber Hose 60120222	2-127, 2-161
Rubber Hose 60120223	2-121, 2-133
Rubber Hose 60120224	2-127
Rubber Hose 60227817	2-131, 2-133
Rubber Hose 60238497	2-127, 2-133
rubber hose 60240242	2-137
rubber hose 60243801	2-33
rubber hose 60246041	2-115
rubber hose 60262327	2-125, 2-135

rubber hose 60262330	2-137
rubber hose 60270116	2-131
Rubber hose 60323298	2-131
Rubber hose B230103000464	2-31
Rubber Hose B230103003046	2-161, 2-163, 3-21
Rubber hose B230103003866	2-163
Rubber Hose B230103004072	2-29
Rubber hose B230103004297	2-31, 2-163
Rubber hose B230103004426	2-111
Rubber hose B230103004474	3-21
Rubber Hose B230103004806	2-37
Rubber hose B230103005165	2-163
Rubber Hose B230103006585	2-33
Rubber Hose B230103007708	2-117
Rubber Mat 61024067	2-77
rubber protective sleeve component 13116120	5-5
Rubber Sleeve 60238623	2-153, 2-155
RubberHose 60255796	2-117, 2-119, 2-121
run-out footplate 14155034	5-5
running control mechanism 13967294	5-5
running valve fixed board 14184768	5-5
S1 Gear 61024452	3-27
S2 GEAR 60258082	2-85
S2 Gear 61024433	3-27
Safety exit lable 13166419	8-5
Safety hammer 60052666	5-13
Safety sign - "Beware of fire 12033806	8-3
Safety Valve 61024071	2-55
Sany Encourage Control Display 14056054	7-3
SANY excavator maintenance and guarantee(English) 11826337	9-3
Screw A210204000354	2-15
Screw M6×55GB70.1 Grade 10.9 A210204000218	4-17
Screw plug 10514225	2-25, 2-43, 3-7
Screw Plug 60082841	2-147
Screw plug B210399000001	2-175
Screw Plug B210780000164	2-175
Screw plug SSY004677093	2-3
Screw 23000063	2-157
Screw 24002251	7-5
SCREW 60164310	2-81, 2-85
SCREW 60164376	3-29
Screw 60171656	2-145
Screw 60249819	2-95, 2-97, 2-109
Screw 60290373	2-143, 2-149
Screw 60290376	2-143
Screw 61008443	2-49
Screw 61008444	2-47
Screw 61008445	2-49
Screw 61008446	2-49
Screw 61008448	2-49
Screw 61008449	2-47
Screw 61024056	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
Screw A210204000129	5-5
Screw A210204000130	2-25, 5-5
Screw A210204000134	2-143, 2-149
Screw A210204000137	2-19
Screw A210204000147	2-87
Screw A210204000181	5-21
Screw A210204000196	2-93
Screw A210204000203	2-17
Screw A210204000220	5-5, 5-7
Screw A210204000335	2-31
Screw A210204000337	2-15, 2-25, 3-3
Screw A210210000002	5-5, 5-7
Screw A210210000008	5-7, 7-5
Screw A210210000023	5-7, 7-5
Screw A210210000030	5-29, 7-5

Seal Kit 61024429	3-27
Seal Kit 61024487	3-31
Seal Ring 60248026	3-9
Seal Washer 60290352	2-165
Seal-O-Ring 60171544	3-23
sealer package 13928198	4-23
sealer package 13928206	4-21
sealer package 13928212	4-19
sealer package 13928216	3-33
sealer package 13928220	2-51
Sealing Plate 13932946	2-9
sealing rubber of front-lower glass 60349308	5-11
sealing rubber strip of door 60248535	5-19
sealing rubber strip of front window 60349295	5-9
sealing sponge 14351881	6-3
Sealing strip 14151076	6-3
seat base assembly 130988000339A	5-37
seat belt 130988000338A	5-37
seat platform 13924614	5-23
Seat safety caution board 13507746	8-5
Seat 60290364	2-143, 2-149
Seat 60290371	2-143, 2-149
Seat 61024470	3-31
Seat 61024521	2-81
Seat 61024530	2-83
Segment 61008474	2-49
Semi-Ring Swash Plate Support 61008463	2-49
Sensor, pressure A820205001061	2-91
Setscrew A810502019056	6-3
shaft 2 13932055	4-5
SHAFT SEAL BABSL 28X40X7 60249509	2-49
Shaft Sleeve 13036982	3-13
Shaft Sleeve 13064724	4-9, 4-13, 4-25
Shaft Sleeve 13064878	4-5, 4-7
Shaft Sleeve 13073008	4-3, 4-25
Shaft Sleeve 13916934	2-5
Shaft Sleeve 14030743	4-3
Shaft Sleeve 14030744	4-3
SHAFT SUB ASSY 60259580	3-29
shaft 13063797	4-5, 4-7
shaft 13063799	4-7
shaft 13072973	4-9
shaft 13072974	4-9
shaft 13072975	4-13
shaft 13073232	4-9
shaft 13916936	4-5
shaft 13916937	4-7, 4-13
SHAFT 60257722	3-29
Shaft 61008473	2-49
Shaft 61024490	2-85
Shaft 61024527	2-81
SHOE HOLDER 60257727	3-29
Shoe Holder 61024519	2-81
SHOE 60257726	3-29
Shoe 61024518	2-81
Shoulder Washer 61008452	2-49
Shuttle Spool 61024474	3-31
skin skirt 130988000343A	5-37
Slewing bearing oil filler mark 13964881	8-3
Slewing Bearing 13863870	3-3
Slewing devic SSY004622756	1-3
Slide Seat 61024437	3-27
slideway assembly 130988000342A	5-37
slideway limit 130988000345A	5-37
sliding window of door 60248546	5-19
SNAP RING 60257737	3-29
SNAP RING 60258092	2-85

SNAP RING 60258116	2-81
Snap Ring 61024440	3-27
Snap Ring 61024441	3-27
Snap Ring 61024449	3-27
Snap Ring 61024456	3-27
Snap Ring 61024457	3-27
Socket 24×12.5GB3390.1 A260401010051	9-5
Socket 60001295	9-5
Socket A260401010025	9-5
Socket A260401010027	9-5
Socket A260401010029	9-5
Socket A260401010063	9-5
Soffietto Circolare 60221098	2-153, 2-155
Solenoid valve 61025255	2-151
Spacer 10574180	4-5
Spacer 13063804	3-5, 4-3, 4-5, 4-7, 4-9, 4-11
Spacer 13068305	2-9
Spacer 13085812	2-7, 3-5, 4-13
Spacer 13529173	4-3
Spacer 61016958	2-141
Spacer 61016962	2-141
Spanner, adjustable A260401040004	9-5
Spanner, belt B260401090024	9-5
Spanner, double-ended A260401030005	9-5
Spanner, double-ended A260401030007	9-5
Speaker 60023703	5-13
Spherical separators 60328517	3-11
Splined Ring 61008462	2-49
Split flow gear pump 60166393	2-171
sponge 14203217	2-9
sponge 14203218	2-9
sponge 14203219	2-9
sponge 14203220	2-9
sponge 14203221	2-9
sponge 14203222	2-9
sponge 14203223	2-9
sponge 14203224	2-9
sponge 14203225	2-9
sponge 14203226	2-9
sponge 14203227	2-9
sponge 14203228	2-9
sponge SSY004596720	6-3
Spool B 61024472	3-31
Spool C 61024473	3-31
Spool Guide 60171597	2-145
Spool 60171582	2-147
Spool 60171583	2-153, 2-155
Spool 60290347	2-165
Spool 60290355	2-165
Spool 60290360	2-143, 2-149
Spool 61024468	3-31
Spool 61024471	3-31
SPRING B 60257744	3-29
SPRING C 60257732	3-29
Spring Pin 61024458	3-27
Spring Pin 61024466	3-29, 3-31
Spring Pin 61024511	2-81
spring plate 60280437	3-9
Spring Seat 61024050	2-55
Spring Seat 61024051	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
Spring Seat 61024052	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
Spring V1 61024475	3-31
Spring V2 61024476	3-31
Spring V3 61024477	3-31
Spring washer 60290361	2-143, 2-149

Spring 60171613	2-147
Spring 60171614	2-147
Spring 60171619	2-153, 2-155
SPRING 60221100	2-153, 2-155
spring 60280436	3-9
Spring 60290335	2-165
Spring 60290344	2-165
Spring 60290349	2-165
Spring 60290353	2-165
Spring 60290362	2-143, 2-149
Spring 60290363	2-143, 2-149
Spring 61016951	2-141
Spring 61016959	2-141
Spring 61016961	2-141
Spring 61024068	2-55
Spring 61024069	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
Spring 61024514	2-81
Spring 61024523	2-81
Spring 61024535	2-83
Steel Ball φ10GB308-89 A210661000022	3-23
Steel ball 60171567	2-145
Steel Ball 60307398	3-11
STEEL PLATE 60257741	3-29
steel tube assembly 13919941	4-15
steel tube assembly 13919945	4-15
steel tube assembly 13919947	4-15
steel tube assembly 13919967	4-15
Steel-wire retainer ring 60290366	2-143, 2-149
Stud Bolt 61024055	2-53
Stud Ends 23000531	2-7
Stud Straight Connector B210780000823	2-91, 2-95, 2-97, 2-99, 2-159, 2-
	167
Suction Hose 14157352	2-27
Sun Gear S1 61024416	2-85
Superstructure Assembly SSY004640646	2-3
Support Drive Torque Limiter 61008460	2-49
Support of rearview mirror (1) 60166737	5-21
Support of rearview mirror (2) 60166738	5-21
Support, left 60153665	9-7
Support, right 60153654	9-7
support 13920595	4-3
supporting lever 13938371	6-3
Swash Plate Group 61024423	2-81
Swash Plate 61008468	2-47
Swash Plate 61024445	3-29
Swash Plate 61024524	2-81
Swing Assy 61024028	2-53
Swing holder 60290372	2-143, 2-149
Swing Spool 61024042	2-63
switch support 14039989	7-3
Swivel Reducing Straight Adapter B210780001391	2-157
SY16 left movable arm marking 13792522	8-3
SY16 right movable arm marking 13792523	8-5
SY26 Loading Information 14155494	9-3
SY26 Maintenance Manual 14155499	9-3
SY26 Operation Manual 14155497	9-3
Tensioner AS 60181276	3-3
Tensioning Equipment Repairing Bag 60248023	3-9
Terminal Assembly,Battery,Negative 60013321	7-3
Terminal Assembly,Battery,Positive 60013322	7-3
three-way joint 13699488	2-171
Thrust Collar 61024436	3-27
Thrust Plate 2 61024507	2-85
Thrust Plate1 61024501	2-85
Thrust Washer 2 61024508	2-85
Thrust Washer1 61024502	2-85
THRUST WASHER 60216956	3-27

Thrust Washer 61024443	3-27
Tl Assy 61024026	2-53
Toolbox, portable A290000000155	9-5
top glass of door 60248544	5-19
top glass rubber 60349300	5-9
top glass 60349299	5-9
top inner plaque 60349324	5-15
top sponge 60349320	5-15
top sponge 60349321	5-15
top sponge 60349322	5-15
top sponge 60349323	5-15
Torque Limiter 61008438	2-47
toxic 13507855	8-5
Tr Assy 61024027	2-53
track roller 12935633	3-3
transitional joint 13699569	2-171
Travel device 14138527	1-3
Travel Spool 61024046	2-59, 2-61
Tray 60153827	9-7
U ring 60290369	2-143, 2-149
Undercarriages hydraulic pipeline 13915543	3-7
Universal joint 61026666	2-153, 2-155
Unload Spool 61024044	2-55
upper cover anchor 60259920	5-39, 5-41
Upper cover 60153777	9-7
Valve block 61025256	2-151
VALVE PLATE 60257724	3-29
Valve Plate 61008470	2-49
Valve Plate 61024516	2-81
Valve pocket 60290342	2-165
Valve pocket 60290359	2-143, 2-149
Valve-heater 60330758	2-173
Valve, shuttle, tee B220400000169	2-93
Valve A229900000882	2-5
wall lamp 60248555	5-13
warm air system equip 13940010	2-3
Washer 60060553	5-3
Washer A210491000121	3-3, 6-3
washer 11578416	2-145
Washer 24000511	2-43
Washer 24000630	5-5, 5-7, 7-5
Washer 24000632	2-19, 2-25, 4-17, 5-5, 5-7, 6-7
Washer 24000633	2-9, 2-13, 2-43, 2-87, 2-171, 3-3, 3-7, 5-5, 5-7, 5-29, 6-3, 6-5
Washer 24000637	2-15, 2-31, 3-5, 3-7, 4-5
Washer 24000639	2-15, 2-25, 4-27, 5-3
Washer 24000642	2-17
Washer 60027775	2-95, 2-97, 2-109
Washer 60060546	7-3
Washer 60060562	5-29
Washer 60060564	2-109
Washer 60060565	6-3
Washer 60290348	2-165
Washer 60290365	2-143, 2-149
Washer 61024066	2-77
Washer 61024455	3-27
Washer 61024536	2-83
Washer A210404000004	4-3
Washer A210404000005	2-9, 4-17
Washer A210405000004	5-7
Washer A210405000007	4-15
Washer A210444000001	3-3
Washer A210491000120	6-3, 6-7
Washer A210491000122	2-11
water jet assembly 60310282	5-15
water pipe 13202041	2-171
water spraying nipple 60166732	5-15

water_out_joint 13055186	2-5
waterproof rubber 13684419	5-3
wind hook component 13003583	6-3
Windshield switch 60330155	2-173
wiper arm assembly 60349309	5-11
wiper arm 60349314	5-11
wiper blade 60349315	5-11
wiper motor 60349313	5-11
Work device Tube 13915517	4-5
Work device SSY004622856	1-3
Work Lamp 60143661	7-3
Wrench rachet A260401090010	9-5
Wrench, Allen 8RGB5356 A260401020011	9-5
Wrench, allen A260401020004	9-5
Wrench, allen A260401020009	9-5
Wrench, allen A260401020010	9-5
Wrench, box end A260401030100	9-5

BLANK PAGE

Appendix B Numerical Index

10124614 Caution plate of bucket rod	8-3
10165802 Connector	2-25
10514225 Screw plug	2-25, 2-43, 3-7
10541251 Connector	2-157, 3-17
10574180 Spacer	4-5
10597771 Cover board	3-5
11133774 Protective Sleeve	3-7
11133805 Protective Sleeve	3-7
11147213 G1/2(ED)-M26-L65 connector	2-13, 2-21
11225694 Protective sleeve	2-9
11578416 washer	2-145
11826337 SANY excavator maintenance and guarantee(English)	9-3
12033806 Safety sign - "Beware of fire"	8-3
12033810 No trample Nameplate	8-7
12052087 Mark Diagram of Hook Point	8-3
12052088 Front window lock caution board	8-3
12688927 Handle, left	5-29
12691132 Right handle	5-29
12824424 Integrated box	7-5
12877195 G1/4(ED)-M14Connector	2-7
12935633 track roller	3-3
12978957 Connector	2-13
12978991 Connector	2-105
12996227 cover plate	2-9
12997846 right tooth	4-27
12997847 left tooth	4-27
12997848 bucket tooth	4-27
13003583 wind hook component	6-3
13036166 Protective sleeve	2-171
13036922 Lock pin	3-5
13036961 Lock pin	2-7, 3-5
13036982 Shaft Sleeve	3-13
13040450 bottom cover plate	3-7
13053059 connector	2-13, 2-159, 2-167
13055186 water_out_joint	2-5
13061324 plate	2-43
13063797 shaft	4-5, 4-7
13063799 shaft	4-7
13063804 Spacer	3-5, 4-3, 4-5, 4-7, 4-9, 4-11
13064724 Shaft Sleeve	4-9, 4-13, 4-25
13064878 Shaft Sleeve	4-5, 4-7
13068305 Spacer	2-9
13072973 shaft	4-9
13072974 shaft	4-9
13072975 shaft	4-13
13073008 Shaft Sleeve	4-3, 4-25
13073232 shaft	4-9
13085812 Spacer	2-7, 3-5, 4-13
13088475 left rubber strip	6-3
130901000064B005 locked rebound assembly	5-9
130901000064B006 back lock	5-9
130988000336A backrest assembly	5-37
130988000337A right cover	5-37
130988000338A seat belt	5-37
130988000339A seat base assembly	5-37
130988000340A left cover	5-37
130988000341A adjust angle handle	5-37
130988000342A slideway assembly	5-37
130988000343A skin skirt	5-37
130988000344A document bag	5-37
130988000345A slideway limit	5-37
13116120 rubber protective sleeve component	5-5

13117643 base plate front sponge	5-5
13146624 Noise marker	8-3
13155987 Leading switch mark	8-3
13156069 Foot pedal mark	8-5
13166419 Safety exit lable	8-5
13166425 Fuel tank indicator	8-7
13166446 Fixed loading spot mark	8-3
13182689 Rubber hose	2-31, 2-167
13202041 water pipe	2-171
13272748 Hydraulic oil tank indicative board	8-7
13328071 lock sleeve	6-5
13335611 Clamp	4-17
13340334 Oil level label	8-7
13411269 Lifting Mark	8-3
13494001 drainage tuble	2-5
13504946 Emergency Stop Switch	8-5
13507562 Control insturction	8-3
13507565 Fan warning	8-5
13507568 Oil-water separator drain instruction	8-5
13507584 High temperature warning	8-5
13507743 Read manual	8-5
13507746 Seat safety caution board	8-5
13507767 Power sign	8-7
13507780 One way/two way valve	8-5
13507819 no open flame	8-5
13507822 Counter rotating rollers	8-5
13507828 Oil level label	8-5
13507855 toxic	8-5
13509503 be care of steam	8-7
13529173 Spacer	4-3
13603234 front pedal	5-33
13603235 back pedal	5-33
13603236 pedal assy	5-29
13603237 front pedal	5-31
13603238 back pedal	5-31
13603239 rotating shaft	5-31, 5-33
13603240 pedal assy	5-29
13603244 pedal	5-27
13603245 rotating shaft	5-27
13603246 pendulum pedal assy	5-5
13603282 Connector	2-23
13623064 G1/4-M14 Connector	2-93
13684419 waterproof rubber	5-3
13699488 three-way joint	2-171
13699569 transitional joint	2-171
13792522 SY16 left movable arm marking	8-3
13792523 SY16 right movable arm marking	8-5
13834945 Name Plate	8-3
13834946 Name Plate	8-3
13845264 installation frame	5-27
13863791 Inner Ring	3-11
13863860 Outer Ring	3-11
13863863 pumping	3-11
13863870 Slewing Bearing	3-3
13891370 guide wheel assy.	3-3
13891396 Driving wheel	3-3
13908742 pipe nip	4-15
13908765 pipe nip	4-15
13913236 counterweight	2-11
13915254 arm cylinder	4-15
13915265 Bucket Oil Cylinder	4-15
13915275 Bucket cylinder assembly	4-17
13915446 Bulldozing shovel oil cylinder	3-19
13915468 Bulldozing shovel oil cylinder	2-31
13915517 Work device Tube	4-5
13915543 Undercarriages hydraulic pipeline	3-7
13916934 Shaft Sleeve	2-5

13916936 shaft	4-5
13916937 shaft	4-7, 4-13
13919736 Bulldozing shovel	3-13
13919739 Bucket	4-13
13919753 Bucket Body	4-27
13919755 Control Switch Harness	7-5
13919779 Driver's Cab Harness	7-5
13919848 Motor cover	3-7
13919859 oil tube	2-25
13919908 arm	4-7
13919911 Oil suction steel tube	2-15
13919934 Oil suction steel tube	2-25
13919941 steel tube assembly	4-15
13919943 Clamp	2-31
13919944 plate	2-31
13919945 steel tube assembly	4-15
13919947 steel tube assembly	4-15
13919967 steel tube assembly	4-15
13920283 boom	4-5
13920316 Oil cylinder protecting board	4-5
13920373 hydraulic oil tank	2-43
13920376 plate	2-43
13920595 support	4-3
13920627 Connecting Rod	4-25
13920675 Rocker	4-9
13920677 Left rocker	4-9
13921221 light cover	4-5
13922459 Counterweight Marking	8-5
13922463 Machine Model Marking	8-5
13922934 Combination Running frame	3-3
13923407 Machine Model Marking	8-3
13923421 Counterweight left reflective coating	8-5
13923425 Counterweight right reflective coating	8-5
13924614 seat platform	5-23
13925158 cup seat	5-5
13925167 pedal	5-5
13925246 bracket of display screen	5-5
13925248 bottom board pad	5-7
13927257 front cover	5-35
13927258 maintenance door	5-35
13927274 maintenance cover	5-5
13927295 blower cover	5-5
13927580 heat insulation sponge of aluminum foil	5-23
13927581 heat insulation sponge of aluminum foil	5-23
13927582 heat insulation sponge of aluminum foil	5-23
13927583 heat insulation sponge of aluminum foil	5-23
13927584 heat insulation sponge of aluminum foil	5-23
13927585 Display harness	7-3
13927671 heat insulation sponge of aluminum foil	5-23
13927672 heat insulation sponge of aluminum foil	5-23
13927673 heat insulation sponge of aluminum foil	5-23
13927674 heat insulation sponge of aluminum foil	5-23
13927675 heat insulation sponge of aluminum foil	5-23
13927676 heat insulation sponge of aluminum foil	5-23
13927678 heat insulation sponge of aluminum foil	5-23
13927679 heat insulation sponge of aluminum foil	5-23
13927865 driver's cab assy.	1-3
13928198 sealer package	4-23
13928206 sealer package	4-21
13928212 sealer package	4-19
13928216 sealer package	3-33
13928220 sealer package	2-51
13932055 shaft 2	4-5
13932946 Sealing Plate	2-9
13937753 revolving frame	2-5
13938315 hinge assy	6-7
13938317 right wall panel	6-3

13938338 bracket assy	6-3
13938343 left door assy	6-3
13938344 assembly of rear hood	6-3
13938352 rear hood	6-7
13938363 right door assy	6-3
13938368 front engine hood assy	6-3
13938369 front engine hood weldment	6-5
13938371 supporting lever	6-3
13938373 connecting board	6-3
13938376 lock catch	6-3
13940010 warm air system equip	2-3
13940022 counterweight assembly	2-5
13944319 Lift capability meter	8-3
13964881 Slewing bearing oil filler mark	8-3
13967294 running control mechanism	5-5
14000776 Coating	1-3
14007919 fix board	5-5
14007920 fix board	5-7
14030741 Lock pin	4-3
14030742 Board	4-3
14030743 Shaft Sleeve	4-3
14030744 Shaft Sleeve	4-3
14030747 Brace piece axial pin	4-3
14036609 Lock pin	4-3
14039767 left wall panel assy	6-3
14039989 switch support	7-3
14042474 Accompanying tools	9-3
14050228 DianYuanXian	7-3
14056054 Sany Encourage Control Display	7-3
14096559 connecting board component	5-5
14136941 Electrical assembly drawing	1-3
14138527 Travel device	1-3
14138545 power system	1-3
14138971 Right engine hood sealant strip	6-3
14138972 Left engine hood sealant strip	6-3
14139093 general assembly of covering parts	1-3
14146001 Rear engine hood sealant strip	6-3
14151076 Sealing strip	6-3
14155034 run-out footplate	5-5
14155494 SY26 Loading Information	9-3
14155497 SY26 Operation Manual	9-3
14155499 SY26 Maintenance Manual	9-3
14157352 Suction Hose	2-27
14172251 bracket	2-5
14184768 running valve fixed board	5-5
14184966 heat insulation sponge of aluminum foil	5-23
14203217 sponge	2-9
14203218 sponge	2-9
14203219 sponge	2-9
14203220 sponge	2-9
14203221 sponge	2-9
14203222 sponge	2-9
14203223 sponge	2-9
14203224 sponge	2-9
14203225 sponge	2-9
14203226 sponge	2-9
14203227 sponge	2-9
14203228 sponge	2-9
14208194 Coating	8-5
14210440 lengthening adaptor	2-15
14219752 control lever	5-29
14219919 right control lever	5-29
14285768 bracket of display screen	5-25
14285771 bracket of display screen	5-25
14333450 heat insulation sponge of aluminum foil	5-23
14333451 heat insulation sponge of aluminum foil	5-23
14351881 sealing sponge	6-3

14373382 FOPS& TOPS Card	8-5
14414127 decal	8-3
14422541 Base assembly	5-3
14518215 cover plate	3-3
14532509 Engine Drawing Volume for SY26C3Y5LU(EU)	9-3
14532534 Drawing volume of parts SY26C3Y5LU(EU)	9-3
14532950 Attached accessories	1-3
14541994 Pipeline of Boom(with maintaining valve)	2-3
14542145 Pipeline Of Arm	2-3
150588000006 Repair Kit	2-143
151003210023A Hose	2-35
151003210024A Hose	2-31
151003210051A Hose AS	3-19
151004210027A Rubber hose	2-41
151004210028A Hose	4-15
151004210029A Hose	2-33, 2-39
151004210030A Hose	3-21
151004210031A Hose	2-37, 2-163
151004210070A Hose AS	4-17
151006210006A Hose	2-39
21000123 O-ring	2-165
21005237 Bolt	3-3
21011030 Fitting, Adapter, Flange	2-15
21011540 Pipe connector	2-93
21018229 Rubber Hose	4-17
21019042 O-ring	2-143, 2-149
21020116 Plug	4-17
21020859 Rubber Hose	2-111
21029124 O-ring	2-165
21053360 Hose ring hoop	2-5
21053567 Pipe connector	2-13
21054224 Rubber Hose	2-115
23000063 Screw	2-157
23000169 Nut	6-7
23000531 Stud Ends	2-7
23904681 Pipe connector	2-87, 2-89, 2-91, 2-93, 2-95, 2-97, 2-99, 2-157, 2-159, 2-167
24000511 Washer	2-43
24000630 Washer	5-5, 5-7, 7-5
24000632 Washer	2-19, 2-25, 4-17, 5-5, 5-7, 6-7
24000633 Washer	2-9, 2-13, 2-43, 2-87, 2-171, 3-3, 3-7, 5-5, 5-7, 5-29, 6-3, 6-5
24000637 Washer	2-15, 2-31, 3-5, 3-7, 4-5
24000639 Washer	2-15, 2-25, 4-27, 5-3
24000642 Washer	2-17
24002251 Screw	7-5
60001295 Socket	9-5
60012591 Pin	3-11
60012803 Power Supply Harness	7-3
60012805 Cable, Battery	7-3
60013321 Terminal Assembly,Battery,Negative	7-3
60013322 Terminal Assembly,Battery,Positive	7-3
60018916 Rubber Hose	2-119
60022417 Center Swivel Joint	3-15
60023703 Speaker	5-13
60023704 Antenna	5-11
60027775 Washer	2-95, 2-97, 2-109
60027935 oil filter	9-3
60041997 Accessories Box	9-3
60050766 Contact Module	7-3
60052666 Safety hammer	5-13
60060546 Washer	7-3
60060553 Washer	5-3
60060562 Washer	5-29
60060564 Washer	2-109
60060565 Washer	6-3
60066402 Battery	7-3

60069757 Rubber Hose	3-21
60078066 Pin	3-11
60082841 Screw Plug	2-147
60086354 Clamp	2-9, 7-3
60101296 Rubber hose	2-41
60114799 Pressure Sensor	2-91
60114999 Filter core	2-43
60120208 Rubber Hose	2-129
60120209 Rubber Hose	2-123, 2-125
60120210 Rubber Hose	2-129
60120211 Rubber Hose	2-135
60120212 Rubber Hose	2-161, 2-169
60120213 Rubber Hose	2-123, 2-169
60120214 Rubber Hose	2-139
60120215 Rubber Hose	2-129
60120217 Rubber Hose	2-139, 2-161
60120222 Rubber Hose	2-127, 2-161
60120223 Rubber Hose	2-121, 2-133
60120224 Rubber Hose	2-127
60123506 Main cartridge of air cleaner	9-3
60129665 Pilot-control Valve	2-93
60136966 Pipe connector	2-87, 2-89, 2-91, 2-93
60140964 Pipe connector	2-89, 2-97, 2-99
60141820 Cross recessed pan head tapping screws	2-147
60143661 Work Lamp	7-3
60147943 Plug	2-147
60153654 Support, right	9-7
60153665 Support, left	9-7
60153693 Latch	9-7
60153697 Handle	9-7
60153713 Base	9-7
60153777 Upper cover	9-7
60153827 Tray	9-7
60164159 BALL	3-29
60164261 PLUG	3-27
60164262 PLUG	3-27
60164263 PLUG	3-27
60164310 SCREW	2-81, 2-85
60164322 PIN	2-81
60164329 PIN	3-29
60164336 Kit, seal	2-81
60164376 SCREW	3-29
60164378 O RING	2-81, 3-29, 3-31
60164379 O RING	2-81, 3-27
60164380 O RING	2-83, 3-27, 3-31
60164381 O RING	2-83
60164384 O RING	2-83
60164385 O RING	2-83
60164386 O RING	3-29, 3-31
60164387 O RING	3-27, 3-31
60166393 Split flow gear pump	2-171
60166732 water spraying nipple	5-15
60166735 Pin rail	5-13
60166737 Support of rearview mirror (1)	5-21
60166738 Support of rearview mirror (2)	5-21
60166748 rearview	5-9
60167908 Filtercore	2-43
60171538 Housing-Swing	3-23
60171539 Retaining ring	3-23
60171540 Rotor	3-23
60171541 Plug	2-145, 3-23
60171542 Pin	3-23
60171543 Retaining ring	3-23
60171544 Seal-O-Ring	3-23
60171545 Rotate sealing	3-23
60171550 Retaining ring	2-145
60171551 Retaining ring	2-153, 2-155

60171553 Retaining ring	2-153, 2-155
60171567 Steel ball	2-145
60171572 Body of valve	2-147
60171579 Body of valve	2-153, 2-155
60171582 Spool	2-147
60171583 Spool	2-153, 2-155
60171597 Spool Guide	2-145
60171613 Spring	2-147
60171614 Spring	2-147
60171619 Spring	2-153, 2-155
60171644 Fixed plate	2-145
60171656 Screw	2-145
60171658 Nameplate	2-147
60171672 Push rod assembly	2-145
60171675 Pin	2-145
60171676 Pin	2-145
60171686 plunger assembly	2-147
60171687 Plunger AS	2-153, 2-155
60171688 Protective sleeve	2-145
60174894 Filter, hydraulic tank breather	2-45
60175301 Pipe connector	2-93, 2-95, 2-159
60176725 Dust Ring	3-5, 4-9, 4-11, 4-13
60176726 Dust Ring	4-5, 4-7
60181276 Tensioner AS	3-3
60193169 Power line	7-3
60202078 Cluster Fixed Lace	7-5
60205959 Angle sealing strip	3-11
60211509 Horn	7-3
60212612 DC contactor	7-3
60215505 fuse	7-7
60215506 fuse	7-7
60215507 fuse	7-7
60215508 fuse	7-7
60215509 fuse	7-7
60215510 fuse	7-7
60215653 Intermediate Relay	7-7
60215655 Intermediate Relay	7-7
60216956 THRUST WASHER	3-27
60218598 Ignition switch	7-5
60221097 FLANGE	2-153, 2-155
60221098 Soffietto Circolare	2-153, 2-155
60221100 SPRING	2-153, 2-155
60221102 BUSHING	2-153, 2-155
60222807 Charger	7-3
60223376 Left armrest box assembly	5-7
60225886 Bolt	2-99
60227817 Rubber Hose	2-131, 2-133
60237031 Breather Valve	2-25
60237043 Alarm lamp	7-3
60238497 Rubber Hose	2-127, 2-133
60238623 Rubber Sleeve	2-153, 2-155
60240242 rubber hose	2-137
60240905 holding valve	2-157
60241333 Batterie Switch	7-3
60243801 rubber hose	2-33
60246041 rubber hose	2-115
60246980 ball valve	2-19, 4-17
60247936 Pilot valve	2-95
60248022 Refiller Valve	3-9
60248023 Tensioning Equipment Repairing Bag	3-9
60248024 Dust Ring	3-9
60248025 Bearing Ring	3-9
60248026 Seal Ring	3-9
60248535 sealing rubber strip of door	5-19
60248544 top glass of door	5-19
60248545 bottom glass of door	5-19
60248546 sliding window of door	5-19

60248547 lock of front window(left)	5-11
60248548 lock of front window(right)	5-11
60248549 lock handle from outside	5-19
60248550 lock of door	5-19
60248551 lock catch of door	5-19
60248555 wall lamp	5-13
60248571 decoration plate of lock	5-19
60248575 handle indoor	5-19
60248578 gas spring	5-11
60248586 pintle of top thermal insulation sponge	5-15
60249509 SHAFT SEAL BABSL 28X40X7	2-49
60249819 Screw	2-95, 2-97, 2-109
60250079 journey switch	5-39
60255796 RubberHose	2-117, 2-119, 2-121
60257722 SHAFT	3-29
60257723 CYLINDER BARREL	3-29
60257724 VALVE PLATE	3-29
60257725 PISTON ASSY	3-29
60257726 SHOE	3-29
60257727 SHOE HOLDER	3-29
60257728 BARREL HOLDER	3-29
60257731 PIN	3-29
60257732 SPRING C	3-29
60257733 RETAINER	3-29
60257734 BEARING	3-29
60257737 SNAP RING	3-29
60257740 DISK PLATE	3-29
60257741 STEEL PLATE	3-29
60257742 BARAKE PISTON	3-29
60257743 BARAKE SPACER	3-29
60257744 SPRING B	3-29
60257745 O RING	2-81, 3-29, 3-31
60257746 O RING	3-29, 3-31
60257747 BACK UP RING	3-29, 3-31
60257748 BACK UP RING	3-29, 3-31
60258082 S2 GEAR	2-85
60258092 SNAP RING	2-85
60258113 FILTER	2-81
60258116 SNAP RING	2-81
60258139 Kit, seal	2-83
60259205 Nut	2-153, 2-155
60259580 SHAFT SUB ASSY	3-29
60259581 CYLINDER BARREL SUB ASSY	3-29
60259919 left armrest box upper cover	5-39
60259920 upper cover anchor	5-39, 5-41
60259921 left armrest box right shell	5-39
60259922 left armrest box left shell	5-39
60259923 hand rail limit	5-39, 5-41
60259924 handle	5-39
60259925 handle lever	5-39
60259927 hand rail	5-39, 5-41
60259930 right armrest box left shell	5-41
60259932 bulldozing shovel bar	5-41
60259936 right armrest box upper cover	5-41
60259937 right armrest box right shell	5-41
60262327 rubber hose	2-125, 2-135
60262330 rubber hose	2-137
60265429 Center Swivel Joint Repairing kit	3-23
60270116 rubber hose	2-131
60273107 fuel oil filter	9-3
60280434 mandrel	3-9
60280435 body cylinder	3-9
60280436 spring	3-9
60280437 spring plate	3-9
60280438 installation plate	3-9
60281431 Proportional Electromagnetic Valve	2-99
60281974 Pilot-control Valve	2-97

60290332 Connection	2-165
60290333 Plug	2-165
60290334 Control piston	2-165
60290335 Spring	2-165
60290336 Piston cover	2-165
60290337 O ring	2-165
60290338 Piston Rod	2-165
60290339 Control Rod	2-165
60290340 Nut	2-165
60290341 Bolt	2-165
60290342 Valve pocket	2-165
60290343 Piston	2-165
60290344 Spring	2-165
60290345 Poppet	2-165
60290346 Plug	2-165
60290347 Spool	2-165
60290348 Washer	2-165
60290349 Spring	2-165
60290350 Plug	2-165
60290351 Plug	2-165
60290352 Seal Washer	2-165
60290353 Spring	2-165
60290354 Retainer ring	2-165
60290355 Spool	2-165
60290356 Plug	2-165
60290357 Body	2-165
60290358 Body	2-143
60290359 Valve pocket	2-143, 2-149
60290360 Spool	2-143, 2-149
60290361 Spring washer	2-143, 2-149
60290362 Spring	2-143, 2-149
60290363 Spring	2-143, 2-149
60290364 Seat	2-143, 2-149
60290365 Washer	2-143, 2-149
60290366 Steel-wire retainer ring	2-143, 2-149
60290367 Piston Rod	2-143, 2-149
60290368 Copper sleeve	2-143, 2-149
60290369 U ring	2-143, 2-149
60290370 Pin	2-143, 2-149
60290371 Seat	2-143, 2-149
60290372 Swing holder	2-143, 2-149
60290373 Screw	2-143, 2-149
60290374 Joystick assembly	2-143
60290375 Dust Cover	2-143
60290376 Screw	2-143
60290377 Cap	2-143
60292211 left armrest box framework	5-39
60306443 rocker switch	5-41
60306446 rocker switch	5-41
60306447 rocker switch	5-41
60307398 Steel Ball	3-11
60309855 gas spring	5-39
60310282 water jet assembly	5-15
60312888 heater assembly SY16	2-171
60323298 Rubber hose	2-131
60328517 Spherical separators	3-11
60328847 Driver cab seat	5-7
60330154 Joint valve	2-173
60330155 Windshield switch	2-173
60330156 Blower	2-173
60330758 Valve-heater	2-173
60334193 Reducer Assembly	3-17
60334194 Reducer Assembly	2-17
60338118 Multiple valve	2-13
60338255 Plunger Pump	2-15
60339991 Damper	5-3
60341342 Locker	5-35

60341344 Middle column handle	5-13
60341526 Cab	5-3
60342181 Electromagnetic reversal valve	2-87
60342357 door lock	6-7
60343115 Rubber crawler	3-3
60346062 Right armrest box assembly	5-7
60349294 front-lower glass	5-9
60349295 sealing rubber strip of front window	5-9
60349296 front window assembly	5-9
60349297 right side glass	5-9
60349298 right sliding window	5-9
60349299 top glass	5-9
60349300 top glass rubber	5-9
60349301 back glass	5-9
60349302 left-back side glass	5-9
60349303 door assembly	5-9
60349304 lower rubber strip of front window	5-17
60349305 glass of front window	5-17
60349306 front window wheel	5-17
60349307 lower window plate(left)	5-11
60349308 sealing rubber of front-lower glass	5-11
60349309 wiper arm assembly	5-11
60349310 lower window plate(right)	5-11
60349311 cabin seal rubber strip	5-11
60349312 plastic cover of windscreen wiper	5-11
60349313 wiper motor	5-11
60349314 wiper arm	5-11
60349315 wiper blade	5-11
60349316 back locker handle	5-13
60349317 left inner plaque	5-13
60349318 radio cover	5-15
60349320 top sponge	5-15
60349321 top sponge	5-15
60349322 top sponge	5-15
60349323 top sponge	5-15
60349324 top inner plaque	5-15
60349325 radio plate	5-15
60349326 arm box screen cover	5-41
60351718 O ring	3-31
60352305 Pilot valve	2-109
60352306 Pilot valve	2-109
60354875 Bonnet lock	6-5
61008437 Flow Compensator	2-47
61008438 Torque Limiter	2-47
61008439 Flow Compensator	2-47
61008440 Cover	2-49
61008441 Roller Bearing	2-49
61008442 Roller Bearing	2-49
61008443 Screw	2-49
61008444 Screw	2-47
61008445 Screw	2-49
61008446 Screw	2-49
61008447 Nut	2-47
61008448 Screw	2-49
61008449 Screw	2-47
61008452 Shoulder Washer	2-49
61008453 O-Ring	2-49
61008454 O-Ring	2-47
61008455 O-Ring	2-49
61008456 O-Ring	2-47
61008457 Ring	2-47
61008458 Ring	2-49
61008459 Ring	2-47
61008460 Support Drive Torque Limiter	2-49
61008461 Eccentric Drive Torque Limiter	2-49
61008462 Splined Ring	2-49
61008463 Semi-Ring Swash Plate Support	2-49

61008464 Cylinders Block	2-49
61008465 Counterbalancing Spring	2-49
61008466 Pistons Spring	2-49
61008467 Connector	2-49
61008468 Swash Plate	2-47
61008469 Pistons Guide Plate	2-49
61008470 Valve Plate	2-49
61008471 Piston	2-49
61008472 Connection Shaft	2-49
61008473 Shaft	2-49
61008474 Segment	2-49
61008475 Pump Body	2-49
61008476 Piston	2-47
61008477 Dowel Pin Elastic	2-49
61008478 Dowel Pin Casehardened	2-49
61008479 Dowel Pin Elastic	2-49
61008480 Dowel Pin Casehardened	2-49
61008481 Dowel	2-49
61008482 Plug	2-49
61008483 Plug	2-47
61008484 Plug	2-47
61008485 Plug	2-49
61008486 Pllinger Pump Repair Kit	2-49
61008600 Lock Nut	2-47
61008601 Lock Nut	2-47
61016944 Mhste Housing	2-141
61016945 Electromagnetic valve	2-141
61016946 Coil	2-141
61016947 Accumulator	2-141
61016948 Accumulator connector	2-141
61016949 O-Ring	2-141
61016950 Ball	2-141
61016951 Spring	2-141
61016952 O-Ring	2-141
61016953 Plug	2-141
61016954 Reducer spool	2-141
61016955 Reducer hosing	2-141
61016956 Cone	2-141
61016957 O-Ring	2-141
61016958 Spacer	2-141
61016959 Spring	2-141
61016960 Plug	2-141
61016961 Spring	2-141
61016962 Spacer	2-141
61016963 Plug	2-141
61016964 Oil source valve repair kit	2-141
61020153 Nut	2-53
61020169 O-ring	2-55
61020174 Plug	2-55
61020176 O-ring	2-55, 2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61020201 O-ring	2-59, 2-61
61024024 Inlet Assy	2-53
61024025 Dozer Assy	2-53
61024026 TI Assy	2-53
61024027 Tr Assy	2-53
61024028 Swing Assy	2-53
61024029 Boom Swing Assy	2-53
61024030 Option1 Assy	2-53
61024031 Option2 Assy	2-53
61024032 Boom Assy	2-53
61024033 Arm Assy	2-53
61024034 Bucket Assy	2-53
61024035 End Assy	2-53
61024036 End Cover	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024037 Bucket Spool	2-75

61024038 Arm Spool	2-73
61024039 Boom Spool	2-71
61024040 Option Spool	2-67, 2-69
61024041 Boom Swing Spool	2-65
61024042 Swing Spool	2-63
61024043 Dozer Spool	2-57
61024044 Unload Spool	2-55
61024045 Compensator spool	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024046 Travel Spool	2-59, 2-61
61024047 Inlet Valve Block	2-55
61024048 Arm Valve Block	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2- 73, 2-75
61024049 End Valve Block	2-77
61024050 Spring Seat	2-55
61024051 Spring Seat	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2- 75
61024052 Spring Seat	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2- 75
61024053 LS Flow Valve	2-55
61024054 Check Valve	2-57, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024055 Stud Bolt	2-53
61024056 Screw	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024057 O Ring	2-55, 2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024058 O Ring	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024059 O Ring	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024060 Plug	2-77
61024061 Plug	2-77
61024062 Plug	2-59, 2-61
61024063 Plug	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024064 Plug	2-55
61024065 Restrictor	2-61
61024066 Washer	2-77
61024067 Rubber Mat	2-77
61024068 Spring	2-55
61024069 Spring	2-57, 2-59, 2-61, 2-63, 2-65, 2-67, 2-69, 2-71, 2-73, 2-75
61024070 Relief Valve	2-57, 2-65, 2-69, 2-71, 2-73, 2-75
61024071 Safety Valve	2-55
61024072 Relief Valve	2-67
61024073 Main Valve Repair Kit	2-53
61024412 Reduction Gears	2-79
61024413 Pinion Gear Group	2-85
61024414 Gear Group 1	2-85
61024415 Gear Group 2	2-85
61024416 Sun Gear S1	2-85
61024417 O Ring	2-85
61024418 Ring Retaining	2-85
61024419 Hydraulic Motor	2-79
61024420 Body Group	2-81
61024421 Bearing	2-81
61024422 Brake Piston Group	2-81
61024423 Swash Plate Group	2-81
61024424 Bearing	2-81
61024425 Reduction Gears	3-25
61024426 Body	3-25
61024427 Body Sub Assy	3-27
61024428 Carrier 2 Sub Assy	3-27
61024429 Seal Kit	3-27
61024430 O Ring	3-27
61024431 B1 Gear	3-27
61024432 Cover	3-27
61024433 S2 Gear	3-27
61024434 Ring	3-27
61024435 O Snap Ring	3-27
61024436 Thrust Collar	3-27
61024437 Slide Seat	3-27

61024439 Needle	3-27
61024440 Snap Ring	3-27
61024441 Snap Ring	3-27
61024442 Hydraulic Motor	3-27
61024443 Thrust Washer	3-27
61024444 Body 2 Sub Assy	3-29
61024445 Swash Plate	3-29
61024446 Body 1 Sub Assy	3-31
61024447 Body	3-27
61024448 Bearing	3-27
61024449 Snap Ring	3-27
61024450 Carrier 2	3-27
61024451 B2 Gear	3-27
61024452 S1 Gear	3-27
61024453 Pin	3-27
61024454 Needle	3-27
61024455 Washer	3-27
61024456 Snap Ring	3-27
61024457 Snap Ring	3-27
61024458 Spring Pin	3-27
61024459 Floating Seat	3-27
61024460 O Ring	3-27
61024461 Name Plate	3-27
61024462 Body 2	3-29
61024463 Control Piston	3-29
61024464 Oil Seal	3-29, 3-31
61024465 Bearing	3-29, 3-31
61024466 Spring Pin	3-29, 3-31
61024467 Body 1	3-31
61024468 Spool	3-31
61024469 Check Valve	3-31
61024470 Seat	3-31
61024471 Spool	3-31
61024472 Spool B	3-31
61024473 Spool C	3-31
61024474 Shuttle Spool	3-31
61024475 Spring V1	3-31
61024476 Spring V2	3-31
61024477 Spring V3	3-31
61024478 Plug	3-31
61024479 Plug	3-31
61024480 Plug	3-31
61024481 Plug	3-31
61024482 Plug	3-31
61024483 Plug	3-31
61024484 O Ring	3-31
61024485 Plug	3-31
61024486 Plug	3-31
61024487 Seal Kit	3-31
61024488 Relief Valve	2-81
61024489 Body	2-85
61024490 Shaft	2-85
61024491 Internal Gear	2-85
61024492 Ring Seal	2-85
61024493 Pre-Load Callar	2-85
61024494 Bearing	2-85
61024495 Bearing	2-85
61024496 Oil Seal	2-85
61024497 Pin	2-85
61024498 Carrier 1	2-85
61024499 Gear B1	2-85
61024500 Needle	2-85
61024501 Thrust Plate1	2-85
61024502 Thrust Washer1	2-85
61024503 Ring 1	2-85
61024504 Carrier 2	2-85
61024505 Gear B2	2-85

61024506 Needle	2-85
61024507 Thrust Plate 2	2-85
61024508 Thrust Washer 2	2-85
61024509 Ring 2	2-85
61024510 Body	2-81
61024511 Spring Pin	2-81
61024512 Check Valve	2-81
61024513 Plug	2-81
61024514 Spring	2-81
61024515 Cylinder Barrel	2-81
61024516 Valve Plate	2-81
61024517 Piston	2-81
61024518 Shoe	2-81
61024519 Shoe Holder	2-81
61024520 Barrel Holder	2-81
61024521 Seat	2-81
61024522 Pin	2-81
61024523 Spring	2-81
61024524 Swash Plate	2-81
61024525 Pin	2-81
61024526 Plate	2-81
61024527 Shaft	2-81
61024528 Brake Piston	2-81
61024529 Disk Plate	2-81
61024530 Seat	2-83
61024531 Body	2-83
61024532 Poppet	2-83
61024533 Piston	2-83
61024534 Cap	2-83
61024535 Spring	2-83
61024536 Washer	2-83
61024537 Back Up Ring	2-83
61025254 Bolt, socket head	2-151
61025255 Solenoid valve	2-151
61025256 Valve block	2-151
61026661 Connector	2-153, 2-155
61026662 Handle	2-155
61026663 Handle	2-153
61026664 Connecting rod	2-153, 2-155
61026665 Nut	2-153, 2-155
61026666 Universal joint	2-153, 2-155
61026667 Joint	2-153, 2-155
61026668 Repair kit,handle	2-155
61026669 Repair kit,handle	2-153
61030659 Radio	7-3
A210110000014 Bolt	3-5, 4-9, 4-13
A210110000323 Bolt	2-7, 3-5, 4-5, 4-7
A210110000384 Bolt	4-5
A210111000012 Bolt	3-5, 3-7, 4-5, 6-3, 7-3
A210111000024 Bolt	4-27
A210111000090 Bolt	3-15
A210111000092 Bolt	5-29
A210111000093 Bolt	4-15
A210111000119 Bolt	4-27
A210111000197 Bolt	6-7
A210111000199 Bolt	4-3
A210111000202 Bolt	5-3
A210111000204 Bolt	6-3
A210111000206 Bolt	3-9
A210111000209 Bolt	3-3
A210111000240 Bolt	2-171
A210111000321 Bolt	2-11
A210111000323 Bolt	2-5, 2-13
A210111000342 Bolt	4-17, 6-3, 6-5
A210111000343 Bolt	2-9, 2-43, 2-89, 3-3, 3-7, 5-5, 5-7, 6-3
A210111000442 Bolt	3-3
A210204000129 Screw	5-5

A210204000130 Screw	2-25, 5-5
A210204000134 Screw	2-143, 2-149
A210204000137 Screw	2-19
A210204000147 Screw	2-87
A210204000181 Screw	5-21
A210204000196 Screw	2-93
A210204000203 Screw	2-17
A210204000218 Screw M6×55GB70.1 Grade 10.9	4-17
A210204000220 Screw	5-5, 5-7
A210204000335 Screw	2-31
A210204000337 Screw	2-15, 2-25, 3-3
A210204000354 Screw	2-15
A210210000002 Screw	5-5, 5-7
A210210000008 Screw	5-7, 7-5
A210210000023 Screw	5-7, 7-5
A210210000030 Screw	5-29, 7-5
A210307000001 Nut	2-5, 2-7
A210307000012 Nut	2-143, 5-29
A210307000015 Nut	2-143, 2-149
A210307000017 Nut	4-27
A210307000028 Nut	5-3
A210307000031 Nut	3-5, 4-5, 4-7, 4-9, 4-13, 4-27
A210307000036 Nut	5-25, 6-3
A210307000055 Nut	5-7
A210322000003 Nut	5-7
A210404000004 Washer	4-3
A210404000005 Washer	2-9, 4-17
A210405000004 Washer	5-7
A210405000007 Washer	4-15
A210414000003 Retainer Ring	2-143, 2-149
A210414000011 Retainer Ring	5-27, 5-31, 5-33
A210444000001 Washer	3-3
A210491000007 Pin	6-3
A210491000120 Washer	6-3, 6-7
A210491000121 Washer	3-3, 6-3
A210491000122 Washer	2-11
A210608000007 O-ring	2-143, 2-149, 2-165
A210608000018 O-ring	2-43
A210608000073 O-ring	2-147
A210608000077 O-ring	2-15, 2-25
A210608000086 O-ring	4-13
A210609000095 O-ring	2-147
A210661000022 Steel Ball φ10GB308-89	3-23
A210804000002 Adaptor Grease	2-7, 3-5, 4-3, 4-5, 4-7, 4-9, 4-11, 4-13
A210855000024 Hoop	2-27
A229900000882 Valve	2-5
A229900001398 Mirror, rear-view	5-21
A229900010160 Pipe connector	2-7, 2-101
A229900010390 Fitting, Adapter	2-21
A241300000059 Fuse Housing	7-5
A250100000174 Gauge, sight glass	2-43
A260401010025 Socket	9-5
A260401010027 Socket	9-5
A260401010029 Socket	9-5
A260401010051 Socket 24×12.5GB3390.1	9-5
A260401010063 Socket	9-5
A260401010092 Connecting rod	9-5
A260401020004 Wrench, allen	9-5
A260401020009 Wrench, allen	9-5
A260401020010 Wrench, allen	9-5
A260401020011 Wrench, Allen 8RGB5356	9-5
A260401030005 Spanner, double-ended	9-5
A260401030007 Spanner, double-ended	9-5
A260401030028 Double-ended spanner	9-5
A260401030100 Wrench, box end	9-5
A260401040004 Spanner, adjustable	9-5
A260401090010 Wrench rachet	9-5

A290000000155 Toolbox, portable	9-5
A810312019061 Rigid board	4-3
A810502019056 Setscrew	6-3
A820205000844 Fitting	3-17
A820205000858 Fitting	2-7
A820205000940 Fitting	2-101, 2-103, 2-157
A820205000944 Adapter, relay	2-93
A820205001061 Sensor, pressure	2-91
A820205002389 G3/8-M18 connector	2-17, 2-103
A820205002445 G1/4-M16connector	3-17
A820601000014 Control indicating board of bulldozing shovel	8-3
A820601990927 Decal, unlock	8-3
A820601991049 Counterweight warning board	8-5
A820603000246 Forward direction indication	8-3
A831213044000 Rubber Hose 1SN6-DKOL-DKOL90-440	2-7, 2-117
A880802040016 O-ring	2-43
B210399000001 Screw plug	2-175
B210780000014 Pipe connector	2-93, 2-99, 2-159
B210780000016 Fitting Tee L-Shape	2-13
B210780000019 Fitting, tee, L-shape	2-103
B210780000024 Fitting Elbow	2-13, 2-17, 2-19, 2-23, 2-89, 2-101, 2-107, 2-157
B210780000029 Fitting, Elbow	2-15
B210780000036 Connector, Pipe	2-23, 3-15
B210780000115 Fitting, Bulkhead Connector	2-163
B210780000143 Connector, pipe	2-101
B210780000164 Screw Plug	2-175
B210780000170 Fitting, Tee, L-shape	2-87, 2-91, 2-93, 2-161
B210780000172 Fitting	2-91
B210780000174 Connectorpipe	3-15
B210780000176 Fitting, Adapter	2-87, 2-91, 2-107
B210780000177 Connector, pipe	2-13
B210780000179 Fitting, Adapter	2-13, 2-19, 4-17
B210780000180 Connector, Pipe	2-13, 2-107, 2-159, 2-167
B210780000232 Connector, Pipe	2-23, 2-105, 3-15
B210780000244 Flange, Split	2-15
B210780000418 Fitting Elbow	2-87, 2-91, 2-93, 2-101, 2-107
B210780000609 Plug	2-23, 3-15
B210780000631 Fitting, Tee	3-15
B210780000636 Fitting, Elbow	2-23
B210780000823 Stud Straight Connector	2-91, 2-95, 2-97, 2-99, 2-159, 2-167
B210780000827 Connector Pipe	2-89
B210780001007 Fitting, Tee	2-21
B210780001045 Fitting	2-91, 2-93
B210780001310 Fitting, Elbow	2-13
B210780001391 Swivel Reducing Straight Adapter	2-157
B220400000169 Valve, shuttle, tee	2-93
B229900000063 Filter, pilot AS	2-89
B230101000047 O-ring	2-93, 2-101, 2-103, 2-157, 3-17
B230101000049 O-ring	2-17, 2-103, 2-143, 2-149
B230101000090 O-Ring	2-157, 3-17
B230101000356 O-ring	2-43
B230101000679 O-ring	2-165
B230103000464 Rubber hose	2-31
B230103000932 Hose AS	2-113
B230103000995 Hose	2-119
B230103002042 hose	2-7
B230103002263 Hose Assembly	2-113
B230103003046 Rubber Hose	2-161, 2-163, 3-21
B230103003389 Hose	2-37
B230103003866 Rubber hose	2-163
B230103004072 Rubber Hose	2-29
B230103004297 Rubber hose	2-31, 2-163
B230103004426 Rubber hose	2-111
B230103004474 Rubber hose	3-21
B230103004806 Rubber Hose	2-37

B230103005165 Rubber hose	2-163
B230103006585 Rubber Hose	2-33
B230103007052 Hose	2-7
B230103007708 Rubber Hose	2-117
B240200000059 Emergency Switch	7-3
B240700000221 Pressure relay	2-93
B260401090024 Spanner, belt	9-5
B260409000015 High pressure grease gun	9-5
SSY004596719 lock catch	6-3
SSY004596720 sponge	6-3
SSY004622756 Slewing device	1-3
SSY004622856 Work device	1-3
SSY004640646 Superstructure Assembly	2-3
SSY004640651 Hydraulic Main Pipeline	2-3
SSY004640655 Pilot pipeline	2-3
SSY004677093 Screw plug	2-3
SSY004684894 pipe nip	4-15
SSY004694494 Connecting RodAssy	4-9, 4-11
SSY004698999 Dozer Blade	3-5



Белгород

Белгородский р-н, п. Новосадовый,
ул. Перспективная, д.11

Волгоград

Ангарская 178, 2 этаж, каб.6

Воронеж

ул. Дорожная, д. 86

Краснодар

Тахтамукайский район,
пгт. Яблоновский, ул. Ленина, д.39А, оф.201

Липецк

ул. Ковалева, д 123 В

Минеральные Воды

ул. Советская, д. 55

Москва

ул. Соколово-Мещерская, д.25, офис 304А/Б

Республика Крым

г. Симферополь Московское шоссе, 11-й километр, литД, этаж 1

Ростов-на-Дону

г. Батайск, Восточное шоссе, 6Д

Самара

Московское шоссе 20 км (поселок Мехзавод),
строение 33, офис 201а

Саратов

1-й Усть-Курдюмский проезд, д. 2